

Geant4 Kernel - part 2

Makoto Asai
SLAC National Accelerator Laboratory

Contents

- Selecting physics models
- Primary particle generator
- Scoring and sensitive detector

Geant4 Physics & Applications

A Monte Carlo toolkit for passage of particles through matter

Geant4 Hadronic Physics

Hadronic interactions involve three main regimes : high energy, with string models (Quark Gluon String (QGS), Fritiof (PYTHIA)), intermediate energy, with intra-nuclear cascade models (Bertini (BERT), binary (BIC)), and low energy, with precompound, Fermi break-up, fission/evaporation, capture at rest models and radioactive decays. From 20 MeV down to thermal energy neutrons are handled by means of cross-section databases, with the High Precision (HP) package.

High Energy
Quark/gluon dominating behavior

Intermediate Energy
Nucleon dominating behavior

Low Energy
Nucleus dominating behavior

Neutron simulation down to thermal energies:

Geant4 can use the same neutron data library that MCNPX. Verification queries of Geant4 and Geant4 output of outgoing neutrons produced in neutron collision.

Geant4 Electromagnetic Physics

The electromagnetic physics covers interactions of pions, muons and electrons, and ionization of all charged particles. A "standard" package offers an implementation suited for applications disregarding effects below a few ~10 keV, and a "low energy" one provides approaches (Livermore, Penelope) for more accurate modeling of atomic shell effects allowing simulation down to ~250 eV. A very low extension, Geant4-DNA, includes particle-molecule effects for an energy limit of ~10 eV. The same approach is developed for silicon.

DNA Scale Level Simulation

Project initiated by the ESA, in view of manned mission to Mars: it is a bottom-up approach of dosimetry. Physics processes are extended down to a few eV, based on particle-molecule cross-sections. The approach is applied also to silicon, for accurate simulation of Single Upset Events.

DNA geometry model simulated : 46 Simulation of water chemical species migration accounting for electrical mutual interaction after a 50 MeV proton irradiation. 30 millions nucleosomes, 6 billions base pairs...

HEP Applications

High Energy Physics has been the first domain to use Geant4 in production, with the BaBar experiment. LHC experiments have been using Geant4 in detector design and are using it in physics analysis. Geant4 is also the simulation engine choice of the next generation of electron machines.

The CMS detector

The ATLAS detector

The recent High Luminosity

Responding to the simulation needs of the LHC era, with the Higgs boson hunting, had been the initial motivation of the creation of the proto-Geant4 project, RD44, in 1994.

Space Applications

Applications of Geant4 in space cover planetary scale simulation for soil level media activation studies, soil composition through X-ray re-emission, space ship simulation for radio-protection and electronic single event upset predictions, electronic chip scale simulation for accurate understanding of single event upset generation. It includes also underground, ground level or satellite cosmic ray experiments simulation.

XMM Newton X-ray telescope, launched in 1999

Radiation effects on its instruments were modeled with Geant4 prior to its launch.

Planetocosmos : a simulation tool for planetary scale particle transport. The red curve is a proton trajectory in the Earth magnetic field, interaction level around a planet, at ground level, and with related activated isotopes can then be predicted.

Medical Applications

Medical Applications interest in Monte Carlo is the accuracy capability in complex structures. Geant4 is used for radio-therapy, proton-carbo-therapy devices, radio-protection and nuclear imaging. Large users communities exist in US, Europe and Japan. CPU performance boost allowed by Geant4 MT or by GPU prototype versions open the possibility for routine usage in treatment planning.


Proton beam line, range shifter and dose deposit simulations in HiBAC (Japan). The proton energy is 150 MeV (TASO IIRL NGS 2007 N60-1).

DICOM geometry and dose calculation with g4Mcrcem a tool.

Projectile Kinetic Energy (GeV)

Projectile de Broglie λ (fm)


- Geant4 offers
 - Electromagnetic processes
 - Hadronic and nuclear processes
 - Photon/lepton-hadron processes
 - Optical photon processes
 - Decay processes
 - Shower parameterization
 - Event biasing techniques
 - And you can plug-in more
- Geant4 provides sets of alternative physics models so that the user can freely choose appropriate models according to the type of his/her application.
 - For example, some models are more accurate than others at a sacrifice of speed.



User classes



- **main()**
 - Geant4 does not provide *main()*.

Note : classes written in **red** are mandatory.
- Initialization classes
 - Use G4RunManager::**SetUserInitialization()** to define.
 - Invoked at the initialization
 - **G4VUserDetectorConstruction**
 - **G4VUserPhysicsList** 
 - **G4VUserActionInitialization**
- Action classes
 - Instantiated in G4VUserActionInitialization.
 - Invoked during an event loop
 - **G4VUserPrimaryGeneratorAction**
 - G4UserRunAction
 - G4UserEventAction
 - G4UserStackingAction
 - G4UserTrackingAction
 - G4UserSteppingAction

- Geant4 does not have any default particles or processes.
 - Even for the particle transportation, you have to define it explicitly.
- Derive your own concrete class from **G4VUserPhysicsList** abstract base class.
 - Define all necessary particles
 - Define all necessary processes and assign them to proper particles
 - Define cut-off ranges applied to the world (and each region)
- Primarily, the user's task is choosing a “pre-packaged” physics list, that combines physics processes and models that are relevant to a typical application use-cases.
 - If “pre-packaged” physics lists do not meet your needs, you may add or alternate some processes/models.
 - If you are brave enough, you may implement your physics list.

🏠 Geant4 Homepage

Physics Reference Manual



10.7 (doc Rev5.0)

CONTENTS

General Information

Particle Decay

Electromagnetic Interactions

Hadronic Physics in GEANT4

Gamma- and Lepto-Nuclear Interactions

Solid State Physics

[Docs](#) » Physics Reference Manual

Physics Reference Manual

Scope of this Manual

The Physics Reference Manual provides detailed explanations of the physics implemented in the GEANT4 toolkit.

The manual's purpose is threefold:

- to present the theoretical formulation, model, or parameterization of the physics interactions included in GEANT4,
- to describe the probability of the occurrence of an interaction and the sampling mechanisms required to simulate it, and
- to serve as a reference for toolkit users and developers who wish to consult the underlying physics of an interaction.

This manual does not discuss code implementation or how to use the implemented physics interactions in a simulation. These topics are discussed in the *User's Guide for Application Developers*. Details of the object-oriented design and functionality of the GEANT4 toolkit are given in the *User's Guide for Toolkit Developers*. The *Installation Guide for Setting up |Geant4| in Your Computing Environment* describes how to get the GEANT4 code, install it, and run it.

Contents

- [General Information](#)
 - [Definition of Terms Used in this Guide](#)
 - [Monte Carlo Methods](#)
 - [Bibliography](#)
 - [Particle Transport](#)
 - [Particle transport](#)
 - [True Step Length](#)

🏠 Geant4 Homepage

PhysicsListGuide



10.7 (doc Rev5.0)

Search docs

CONTENTS:

Physics List Guide

Reference Physics Lists

Electromagnetic physics constructors

Hadronic Physics

[Docs](#) » Guide for Physics Lists

Guide for Physics Lists

Scope of this Manual

This guide is a description of the physics lists class which is one of the mandatory user classes for a GEANT4 application. For the most part the "reference" physic lists included in the source distribution are described here as well the modularity and electronic options. Some use cases and areas of application are also described.

Contents:

- [Physics List Guide](#)
 - [Bibliography](#)
- [Reference Physics Lists](#)
 - [FTFP_BERT](#)
 - [QBBC](#)
 - [QGSP_BERT](#)
 - [QGSP_BIC](#)
 - [Shielding](#)
- [Electromagnetic physics constructors](#)
 - [EM physics constructors](#)
 - [EM Opt0](#)
 - [EM Opt1](#)
 - [EM Opt2](#)
 - [EM Opt3](#)
 - [EM Opt4](#)
 - [EM Liv](#)
 - [EM Pen](#)
 - [EM GS](#)
 - [EM LE](#)

- FTFP_BERT
 - Recommended for most of the use-cases
 - “Reference” to be used as the starting point
- QBBC
 - Recommended for medical and space engineering use-cases
- Shielding
 - Recommended for radiation shielding and deep-underground experiments

```
#include "QBBC.hh"
int main(int argc, char** argv)
{
    auto* runManager =
        G4RunManagerFactory::CreateRunManager(G4RunManagerType::Default);

    runManager->SetUserInitialization(new B1DetectorConstruction());

    runManager->SetUserInitialization(new QBBC);
}
```


- EM Option 0 is by default used by all physics lists recommended in the previous slide.
- EM Option 1 (`_EMV`)
 - Faster than Option 0 with relatively low accuracy
- EM Option 4 (`_EMZ`)
 - Most accurate, with additional CPU cost
- EM GS (`_GS`)
 - Same as Option 0 except Goutsmit-Sounderson multiple-scattering mode (more accurate)
- EM SS (`_SS`)
 - No multiple-scattering, only single-scattering is used.
 - Only for low-energy applications
- EM Liv (`_LIV`)
 - Livermore EM physics models are used where applicable
- EM DNA (`_DNA`)
 - For DNA physics/chemistry

- Use G4PhysListFactory and specify the EM option name appended to your choice of the reference physics list.

```
#include "G4PhysListFactory.hh"
int main(int argc,char** argv)
{
    auto* runManager = new G4MTRunManager();


    runManager->SetUserInitialization(new B1DetectorConstruction());

    G4PhysListFactory factory;
    auto* physList = factory.GetReferencePhysicsList("FTFP_BERT_EMZ");
    runManager->SetUserInitialization(physList);
}
```

- Further extensions can be added to the physics list/
 - Optical photon generation (e.g. Cherenkov)
 - Optical photon transport processes
 - Artificial track killer (e.g. neutron killer)
 - Event biasing

```
#include "G4PhysListFactory.hh"
#include "G4NeutronTrackingCut.hh"
int main(int argc, char** argv)
{
    auto* runManager = new G4MTRunManager();
    runManager->SetUserInitialization(new B1DetectorConstruction());


    G4PhysListFactory factory;
    auto* physList = factory.GetReferencePhysicsList("FTFP_BERT_EMZ");
    auto* neutronKiller = new G4NeutronTrackingCut();
    neutronKiller->SetTimeLimit(100.*CLHEP::s);
    physList->RegisterPhysics(neutronKiller);
    runManager->SetUserInitialization(physList);
}
```



GEANT4
A SIMULATION TOOLKIT

Version 10.7.p02


Primary vertex and Primary particle



User classes




- **main()**
 - Geant4 does not provide *main()*.

Note : classes written in **red** are mandatory.
- Initialization classes
 - Use G4RunManager::**SetUserInitialization()** to define.
 - Invoked at the initialization
 - **G4VUserDetectorConstruction**
 - **G4VUserPhysicsList**
 - **G4VUserActionInitialization**
- Action classes
 - Instantiated in G4VUserActionInitialization.
 - Invoked during an event loop
 - **G4VUserPrimaryGeneratorAction** 
 - G4UserRunAction
 - G4UserEventAction
 - G4UserStackingAction
 - G4UserTrackingAction
 - G4UserSteppingAction

- Primary particle means particle with which you start an event.
 - E.g. particles made by the primary p-p collision, an alpha particle emitted from radioactive material, a gamma-ray from treatment head, etc.
 - Then Geant4 tracks these primary particles in your geometry with physics interactions and generates secondaries, detector responses and/or scores.
- Primary vertex has position and time. Primary particle has a particle ID, momentum and optionally polarization. One or more primary particles may be associated with a primary vertex. One event may have one or more primary vertices.

G4PrimaryVertex objects
= {position, time}



G4PrimaryParticle objects
= {PDG, momentum,
polarization...}

- Generation of primary vertex/particle is one of the user-mandatory tasks.
G4VUserPrimaryGeneratorAction is the abstract base class to **control** the generation.
 - Actual generation should be delegated to G4VPrimaryGenerator class. Several concrete implementations, e.g. G4ParticleGun, G4GeneralParticleSource, are provided.

- This class is one of mandatory user classes to **control the generation** of primaries.
 - This class itself **should NOT** generate primaries but **invoke `GeneratePrimaryVertex()`** method of primary generator(s) to make primaries.
- Constructor
 - Instantiate primary generator(s)
 - Set default values to it(them)
- **GeneratePrimaries()** method
 - Invoked at the beginning of each event.
 - Randomize particle-by-particle value(s)
 - Set these values to primary generator(s)
 - Never use hard-coded UI commands
 - Invoke **GeneratePrimaryVertex()** method of primary generator(s)
- Your concrete class of G4VUserPrimaryGeneratorAction must be instantiated in the **Build()** method of your **G4VUserActionInitialization**

Constructor :
Invoked only once

```
MyPrimaryGeneratorAction::MyPrimaryGeneratorAction()
{
    G4int n_particle = 1;
    fparticleGun = new G4ParticleGun(n_particle);


    // default particle kinematic
    G4ParticleTable* particleTable = G4ParticleTable::GetParticleTable();
    G4ParticleDefinition* particle = particleTable->FindParticle("gamma");
    fparticleGun->SetParticleDefinition(particle);
    fparticleGun->SetParticleMomentumDirection(G4ThreeVector(0.,0.,1.));
    fparticleGun->SetParticleEnergy(100.*MeV);
    fparticleGun->SetParticlePosition(G4ThreeVector(0.,0.,-50*cm));
}

Invoked once  
per each event
```

void MyPrimaryGeneratorAction::GeneratePrimaries(G4Event* anEvent)

```
{
    fparticleGun->SetParticleMomentum(G4RandomDirection());
    fparticleGun->GeneratePrimaryVertex(anEvent);
}
```


Primary vertex and primary particle




- Primary vertices and primary particles are stored in G4Event in advance to processing an event.
 - **G4PrimaryVertex** and **G4PrimaryParticle** classes
 - These classes don't have any dependency to G4ParticleDefinition nor G4Track.
 - Capability of bookkeeping decay chains
 - Primary particles **may not** necessarily be particles which can be tracked by Geant4.
- Geant4 provides some concrete implementations of **G4VPrimaryGenerator**.
 - G4ParticleGun
 - G4GeneralParticleSource
 - G4HEPEvtInterface, G4HEPMCInterface


Pre-assigned decay products

- Physics generator can assign a decay channel for **each individual particle separately**.
 - Decay chain can be “pre-assigned”. Without pre-assigned decay channel. Geant4 naively looks up the decay table.
 - `G4PrimaryParticle::SetDaughter(G4PrimaryParticle*)`
- A parent particle in the form of `G4Track` object travels in the detector, bringing “pre-assigned” decay daughters as objects of `G4DynamicParticle`.
 - When the parent track comes to the decay point, pre-assigned daughters become to secondary tracks, instead of randomly selecting a decay channel defined to the particle type. Decay time of the parent can be pre-assigned as well.


G4PrimaryParticle



G4Track



pre-assigned decay products



Pre-assigned decay products


```
auto* primVertex = new G4PrimaryVertex(x0,y0,z0,t0);
auto* b_minus = new G4PrimaryParticle(pdg,px,py,pz);
primVertex->SetPrimary(b_minus);
auto* d_zero = new G4PrimaryParticle(pdg,px,py,pz);
auto* mu_minus = new G4PrimaryParticle(pdg,px,py,pz);
auto* mnu_bar = new G4PrimaryParticle(pdg,px,py,pz);
b_minus->SetDaughter(d_zero);
b_minus->SetDaughter(mu_minus);
b_minus->SetDaughter(mnu_bar);
auto* K_minus = new G4PrimaryParticle(pdg,px,py,pz);
auto* mu_plus = new G4PrimaryParticle(pdg,px,py,pz);
auto* mnu = new G4PrimaryParticle(pdg,px,py,pz);
```

```
d_zero->SetDaughter(K_minus);
d_zero->SetDaughter(mu_plus);
d_zero->SetDaughter(mnu);
g4event->SetPrimaryVertex(primVertex);
```


Note:

- Momenta of daughters can be given in arbitrary frame. Daughters are Lorentz-boosted at the mother's decay point.
- If a parent particle is not a particle known to Geant4 (e.g. W-boson), it is ignored, and daughters are directly converted into G4Track objects.


G4PrimaryParticle



G4Track



pre-assigned decay products



Built-in primary particle generators

- Concrete implementations of G4VPrimaryGenerator
 - A good example for experiment-specific primary generator implementation
- It shoots one primary particle of a certain energy from a certain point at a certain time to a certain direction.
 - Various set methods are available
 - Intercoms commands are also available for setting initial values
- One of most frequently asked questions is :
I want “particle shotgun”, “particle machinegun”, etc.
- Instead of implementing such a fancy weapon, in your implementation of UserPrimaryGeneratorAction, you can
 - Shoot random numbers in arbitrary distribution
 - Use set methods of G4ParticleGun
 - Use G4ParticleGun as many times as you want
 - Use any other primary generators as many times as you want to make overlapping events

- In the constructor of your UserPrimaryGeneratorAction
 - Instantiate G4ParticleGun
 - Set default values by set methods of G4ParticleGun
 - Particle type, kinetic energy, position and direction
- In your macro file or from your interactive terminal session
 - Set values for a run
 - Particle type, kinetic energy, position and direction
- In the GeneratePrimaries() method of your UserPrimaryGeneratorAction
 - Shoot random number(s) and prepare track-by-track or event-by-event values
 - Kinetic energy, position and direction
 - Use set methods of G4ParticleGun to set such values
 - Then invoke GeneratePrimaryVertex() method of G4ParticleGun
 - If you need more than one primary tracks per event, loop over randomization and GeneratePrimaryVertex().
- `examples/basic/B5/src/B5PrimaryGeneratorAction.cc` is a good example to start with.

```
void T01PrimaryGeneratorAction::
    GeneratePrimaries(G4Event* anEvent)
{ G4ParticleDefinition* particle;
  G4int i = (int)(5.*G4UniformRand());
  switch(i)
  { case 0: particle = positron; break; ... }
  particleGun->SetParticleDefinition(particle);
  G4double pp =
    momentum+(G4UniformRand()-0.5)*sigmaMomentum;
  G4double mass = particle->GetPDGMass();
  G4double Ekin = sqrt(pp*pp+mass*mass)-mass;
  particleGun->SetParticleEnergy(Ekin);
  G4double angle = (G4UniformRand()-0.5)*sigmaAngle;
  particleGun->SetParticleMomentumDirection
    (G4ThreeVector(sin(angle),0.,cos(angle)));
  particleGun->GeneratePrimaryVertex(anEvent);
}
```

- You can repeat this for generating more than one primary particles.

- A concrete implementation of G4VPrimaryGenerator
 - Suitable especially to space applications

```
MyPrimaryGeneratorAction::
```

```
    MyPrimaryGeneratorAction()
```

```
{ generator = new G4GeneralParticleSource; }
```

```
void MyPrimaryGeneratorAction::
```

```
    GeneratePrimaries(G4Event* anEvent)
```

```
{ generator->GeneratePrimaryVertex(anEvent); }
```

- Detailed description

[Section 2.7 of Application Developer's Guide](#)

Example commands of General Particle Source

two beams in a generator

```
#
# beam #1
# default intensity is 1 now change to 5.
/gps/source/intensity 5.
```

```
#
/gps/particle proton
/gps/pos/type Beam
```

```
#
# the incident surface is in the y-z plane
```

```
/gps/pos/rot1 0 0 1
```

```
/gps/pos/rot2 0 0 1
```

```
#
```

```
# the beam spot is centered at the origin and is of
```

```
# 1d gaussian shape with a 1 mm central plateau
```

```
/gps/pos/shape Circle
```

```
/gps/pos/centre 0. 0. 0. mm
```

```
/gps/pos/radius 1. mm
```

```
/gps/pos/sigma_r .2 mm
```

```
#
```

```
# the beam is travelling along the X_axis with
```

```
# 5 degrees dispersion
```

```
/gps/ang/rot1 0 0 1
```

```
/gps/ang/rot2 0 0 1
```

```
/gps/ang/type beam1d
```

```
/gps/ang/sigma_r 5. deg
```

```
#
```

```
# the beam energy is in gaussian profile
```

```
# centered at 400 MeV
```

```
/gps/ene/type Gauss
```

```
/gps/ene/mono 400 MeV
```

```
/gps/ene/sigma 50. MeV
```

(macro continuation...)

beam #2

```
# 2x the intensity of beam #1
```

```
/gps/source/add 10.
```

```
#
```

```
# this is a electron beam
```

```
/gps/particle e-
```

```
/gps/pos/type Beam
```

```
# it beam spot is of 2d gaussian profile
```

```
# with a 1x2 mm2 central plateau
```

```
# it is in the x-y plane centred at the origin
```

```
/gps/pos/centre 0. 0. 0. mm
```

```
/gps/pos/halfx 0.5 mm
```

```
/gps/pos/halfy 1. mm
```

```
/gps/pos/sigma_x 0.1 mm
```

```
# the spread in y direction is stronger
```

```
/gps/pos/sigma_y 0.2 mm
```

```
#
```

```
#the beam is travelling along -Z_axis
```

```
/gps/ang/type beam2d
```

```
/gps/ang/sigma_x 2. deg
```


```
/gps/ang/sigma_y 1. deg
```

```
# gaussian energy profile
```


```
/gps/ene/type Gauss
```

```
/gps/ene/mono 600 MeV
```


```
/gps/ene/sigma 50. MeV
```




Source Energy Spectrum




Source X-Z distribution




Source cos(theta)-phi distribution



Source X-Y distribution



Source Y-Z distribution



Source theta/phi distribution

- Concrete implementations of G4VPrimaryGenerator
 - A good example for experiment-specific primary generator implementation
- G4HEPEvtInterface
 - Suitable to /HEPEVT/ common block, which many of (FORTRAN) HEP physics generators are compliant to.
 - ASCII file input
- G4HepMCInterface
 - An interface to HepMC class, which a few new (C++) HEP physics generators are compliant to.
 - ASCII file input or direct linking to a generator through HepMC.

Retrieving information from Geant4

- Given geometry, physics and primary track generation, Geant4 does proper physics simulation “silently”.
 - You have to do something to **extract information useful to you**.
- There are three ways:
 - Built-in scoring commands
 - Most commonly-used physics quantities are available.
 - Use scorers in the tracking volume
 - Create scores for each event
 - Create own Run class to accumulate scores
 - Assign **G4VSensitiveDetector** to a volume to generate “hit”.
 - Use user hooks (G4UserEventAction, G4UserRunAction) to get event / run summary
- You may also use user hooks (G4UserTrackingAction, G4UserSteppingAction, etc.)
 - You have full access to almost all information
 - Straight-forward, but do-it-yourself. Be careful of thread-safety!!



This talk





Command-based scoring

- Command-based scoring functionality offers the built-in scoring mesh and various scorers for commonly-used physics quantities such as dose, flux, etc.
 - Due to small performance overhead, it does not come by default.
- To use this functionality, access to the G4ScoringManager pointer after the instantiation of G4(MT)RunManager in your *main()*.

```
#include "G4ScoringManager.hh"
int main()
{
    auto* runManager = new G4MTRunManager;
    auto* scoringManager = G4ScoringManager::GetScoringManager();
    ...
}
```

- All of the UI commands of this functionality are in /score/ directory.
- /examples/extended/runAndEvent/RE03

Command-based scorers



Define a scoring mesh



- To define a scoring mesh, the user has to specify the followings.
 1. **Shape and name** of the 3D scoring mesh.
 - Currently, box and cylinder are available.
 2. Size of the scoring mesh.
 - Mesh size must be specified as "**half width**" similar to the arguments of G4Box / G4Tubs.
 3. **Number of bins** for each axes.
 - Note that too many bins causes immense memory consumption.
 4. Specify position and rotation of the mesh.
 - If not specified, the mesh is positioned at the center of the world volume without rotation.

```
# define scoring mesh
/score/create/boxMesh boxMesh_1
/score/mesh/boxSize 100. 100. 100. cm
/score/mesh/nBin 30 30 30
/score/mesh/translate/xyz 0. 0. 100. cm
```

- The mesh geometry can be completely independent to the real material geometry.

Scoring quantities

- A mesh may have arbitrary number of scorers. Each scorer scores one physics quantity.
 - energyDeposit * Energy deposit scorer.
 - cellCharge * Cell charge scorer.
 - cellFlux * Cell flux scorer.
 - passageCellFlux * Passage cell flux scorer
 - doseDeposit * Dose deposit scorer.
 - nOfStep * Number of step scorer.
 - nOfSecondary * Number of secondary scorer.
 - trackLength * Track length scorer.
 - passageCellCurrent * Passage cell current scorer.
 - passageTrackLength * Passage track length scorer.
 - flatSurfaceCurrent * Flat surface current Scorer.
 - flatSurfaceFlux * Flat surface flux scorer.
 - nOfCollision * Number of collision scorer.
 - population * Population scorer.
 - nOfTrack * Number of track scorer.
 - nOfTerminatedTrack * Number of terminated tracks scorer.

/score/quantity/xxxxx <scorer_name> <unit>

- Each scorer may take a filter.
 - charged * Charged particle filter.
`/score/filter/kineticEnergy <fname> <eLow> <eHigh> <unit>`
 - neutral * Neutral particle filter.
`/score/filter/particle <fname> <p1> ... <pn>`
 - kineticEnergy * Kinetic energy filter.
`/score/filter/ParticleWithKineticEnergy
<fname> <eLow> <eHigh> <unit> <p1> ... <pn>`

```
/score/quantity/energyDeposit eDep MeV  
/score/quantity/nOfStep nOfStepGamma  
/score/filter/particle gammaFilter gamma  
/score/quantity/nOfStep nOfStepEMinus  
/score/filter/particle eMinusFilter e-  
/score/quantity/nOfStep nOfStepEPlus  
/score/filter/particle ePlusFilter e+
```

Same primitive scorers
with different filters
may be defined.

```
/score/close
```



Close the mesh when defining scorers is done.

- Projection

`/score/drawProjection <mesh_name> <scorer_name> <color_map>`

- Slice

`/score/drawColumn <mesh_name> <scorer_name> <plane> <column>
<color_map>`

- Color map

- By default, linear and log-scale color maps are available.
- Minimum and maximum values can be defined by
`/score/colorMap/setMinMax` command. Otherwise, min and max values are taken from the current score.

- This functionality allows the user to locate scoring “probes” at arbitrary locations.
 - A “probe” is a virtual cube, to which any Geant4 primitive scorers could be assigned.
 - This is an alternative to a scoring mesh, where cells of three-dimensional mesh are touching each other.

```
/score/create/probe <probeName> <halfWidth> <unit>  
/score/probe/locate <x> <y> <z> <unit>
```
- The user can locate an arbitrary number of probes by repeating `/score/probe/locate` commands, but all of these probes are the same shape.
 - Given these probes are located in an artificial “parallel world”, probes may overlap to the volumes defined in the mass geometry, as long as probes themselves are not overlapping to each other or protruding from the world volume.
- In addition, the user may optionally set a material to the probe.
 - Once a material is set to the probe, it overwrites the material(s) defined in the mass geometry when a track enters the probe cube.
 - Because of this overwriting, physics quantities that depend on material or density, e.g. energy deposition or dose, would be measured accordingly to the specified material.
 - Please note that this overwriting material obviously affects to the simulation results, so the size and number of probes should be reasonably small to avoid significant side effects.

- Once a probe is defined, the user can associate arbitrary number of primitive scorers and filters like the ordinary scoring mesh.
 - All probes have the same types scorers but score individually.

```
/score/create/probe Probes 5 cm  
/score/probe/material G4_WATER  
/score/probe/locate 0 0 0 cm  
/score/probe/locate 25 0 0 cm  
/score/probe/locate 0 25 0 cm  
/score/probe/locate 0 0 25 cm  
/score/quantity/doseDeposit dose mGy  
/score/quantity/volumeFlux volFlx  
/score/quantity/volumeFlux protonFlux  
/score/filter/particle protonFilter proton  
/score/close
```



- Alternative to the scoring probe discussed in the previous section, the user may define primitive scorers to a logical volume in the mass geometry.
 - This real-world volume scorer may take any */score/quantity/* commands.

```
/score/create/realWorldLogVol <logVolName> <level>
```

- where *<logVolName>* is the name of the logical volume that appears in the mass geometry, and it is also used as the name of the probe.
- If more than one physical volumes share the same logical volume, scores are filled individually with the copy number of the physical volume as the index.
 - If *<level>* is set, the copy number of the *<level>*-th higher ancestor in the geometrical hierarchy is used as the index.

- Single score
 /score/dumpQuantityToFile <mesh_name> <scorer_name> <file_name>
- All scores
 /score/dumpAllQuantitiesToFile <mesh_name> <file_name>
- By default, values are written in CSV.
- By creating a concrete class derived from **G4VScoreWriter** base class, the user can define his own file format.
 - Example in /examples/extended/runAndEvent/RE03
 - User's score writer class should be registered to G4ScoringManager.