

# OSU Light Collection

## 2/24/25

Sam Corey




THE OHIO STATE UNIVERSITY


---

# So far: 10x10x1.6 with and without wrapping

Horizontal Profiles




Diagonal Profiles




- As of last week, we have scans of this tile with no dimple or optical grease
- Tried wrapped vs. unwrapped. Also checked response of bare SiPM

# Swap to another tile: 11.5x11.5 painted

Horizontal Profiles




Diagonal Profiles




- ~3x higher yield than wrapped at center of the tile
  - ~10x higher yield at the edge
- Now add optical grease

# 11.5x11.5 painted w/ optical grease

Horizontal Profiles




Diagonal Profiles




- Another >3x improvement!
- Painted tiles+optical grease seems very good!
- But still not very uniform->check out tiles with a dimple.

# 11.5x11.5x0.4 bare tile w/ optical grease

Horizontal Profiles



Diagonal Profiles



- Forthcoming: Wrap these, test again, then paint them. Also, various 5x5 tiles.

# Backup

# List of available sample tiles

## Polished+milled to correct size

- ~20 2.4x2.4x0.4 with dimple
- 1 2.4x2.4x0.4 painted with dimple
- 3 4.7x4.7x0.4 with dimple
- 1 4.7x4.7x0.4 painted with dimple
- 1 4.7x4.7x0.4 wrapped with dimple
- 2 5x5x0.4
- 1 5x5x1.6
- 1 10x10x1.6

## Unpolished+not milled to stated size.


- 3 5x5x0.4
- 2 5x5x0.8
- 1 5x5x0.8 with dimple
- 3 5x5x1.6
- 1 10x10x0.4
- 1 10x10x0.4 with dimple
- 3 10x10x0.8
- 3 10x10x1.6

About ~2cm  
extra material  
in x,y

Will show results from this one today

# Polishing the unpolished tiles


- Recently started polishing some of the un-milled tiles by hand.
- Here's an example



Polished


Original

# Lab setup



- Sr90 beta source
- Source moved through a list of positions via x-y table
- Tile centered over SiPM
- Readout through CAEN module


# Lab setup (pt 2)



- For data taking, cover tile with felt and turn off the lights

# Results from unwrapped, polished 10x10 tile

- Horizontal scan across the center of the tile:




Vertical lines=edge of the tile

# Results from unwrapped, polished 10x10 tile


- 1/8<sup>th</sup> grid scan

X vs. y vs. yield


Original Square Response Data



$\sqrt{x^2 + y^2}$  vs yield





# Heatmap from exploiting square symmetry




# Results from wrapped, polished 10x10 tile

- 1/8<sup>th</sup> grid scan



Note: ignore these high yield points at 75, 75  
I suspect due to my phone flashlight checking if it was done

# Heatmap from exploiting square symmetry




Clear improvement from unwrapped case, but very far from ideal.

Maybe wrapping can be improved (better technique/methodology)

Possible improvement by adding layer of reflective material over the PCB with only a very small hole for the SiPM. Could be that the whole cut into the tile's wrapping is too large.


# Scan with no tile

- Repeat the same scan as before but with no tile at all
- This contributes some to the non-uniformity.  $\sim 7.5\%$  overestimating most central region of tile.
- Great to know, but doesn't solve issues.



On the list: painted 10x10 tile, extra mechanical pressure, optical grease  
Also, will try move SiPM to edge of tile, but this will take longer to set up.

# “Improved” wrapping results



One (of many) questions: is it possible that we are uniform above ~25 cm and we're seeing our source directly at the 0cm peak?

