Measurement of Short-Lived Fission Product Yields for ²³⁷Np via γ -ray Spectroscopy

November 1, 2020

Sean Burcher



LLNL-PRES-816148



This work was performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under contract DE-AC52-07NA27344. Lawrence Livermore National Security, LLC

Motivation

- Accurate Fission Product Yields (FPYs) are important for basic and applied science
 - FPYs from a fission neutron spectrum is of particular interest
- Short-lived ($t_{1/2} \sim \text{minutes} \text{hours}$) FPYs are difficult to measure
 - Separation methods require time
- High resolution γ-ray spectroscopy
 - Count the entire sample
 - Simultaneous measurement of FPYs for many isotopes
 - No need to take time to do chemistry/separation





Experimental Setup

- Four ²³⁷Np samples were irradiated in GODIVA critical assembly
 - Neptunium Nitrate (NpO₂(NO₃)) sealed in Quartz tubes
 - Masses: 6.0(1), 10.6(7), 20.3(2), and 44.3(5) mg
 - Neutron Flux: ~ 3×10^{14} neutrons/second
 - Irradiation time: ~ 50 μs (FWHM)
- Samples were retrieved and delivered to γ -ray counting setup ~ 50 minutes after irradiation
- Counting continued for 7 days following irradiation
 - Short Timescale for first 3 hours
 - 10.6(7) mg sample
 - Long Timescale for next 7 days
 - 26.3(3) mg (6.0 + 20.3) samples







Data Analysis : Full Sum Spectrum

• The entire γ -ray spectrum from the long timescale count





Data Analysis : Time Dependent Spectra

- Parse data into time-binned matices
- Fit a peak in each in time bin and plot the intensity versus time (decay curve)
 Use half-life and γ-ray energy to identify isotope
- Use decay curve to extract the activity of the isotope immediately after irradiation



Short Time Scale Data (Detector 8815)

Long Time Scale Data (Detector 8815)



Data Analysis : Cascade Plots





Data Analysis : Cascade Plots

- Used to build γ-ray 'input deck'
 - List of expected γ-rays with energy and time windows
- Easily identify time dependence of γ-ray spectrum
- Helps identify interfering γ-rays





Results : Example ⁹³Y

- Observed 3 'clean' γ -rays from the decay of ⁹³Y
- Extrapolate Decay Curve fits back to irradiation time : A₀
 - Correct for DAQ livetime, detection efficiency, and selfattenuation

$$Y = \frac{A_0 t_{1/2}}{\ln(2) \Gamma N_f}$$
$$\Gamma : Branching Ratio$$
$$N_f : Number of Fissions$$

$$C(t_1, t_2) = \int_{t_1}^{t_2} A(t)dt = \frac{A_0}{\lambda}e^{-\lambda t_2}(e^{\lambda\Delta t} - 1)$$





Results : Example ⁹³Y







Lawrence Livermore National Laboratory

Determining the Number of Fissions

- Four γ-rays from isotopes with well-known FPYs were selected as reference yields
 - Chosen to span a range of:
 - γ-ray energy
 - Isotope half-life
 - Isotope atomic number (Z)
 - Solid and Gas

STAYSL PNNL:

 $7.2(3) \times 10^{11}$ fissions/gram (based on witness foil analysis performed by B. Pierson PNNL)

Number of Fissions in the Sample 2 (Short time-scale count)

Isotope	E_{γ} (keV)	Г	unc.	$t_{1/2}$ (m)	unc.	Ref. Y	unc.	N_{f}	unc.
⁸⁷ Kr	402.6	0.50	0.03	76.3	0.5	1.74	0.05	7.75E + 09	5.22E + 08
^{92}Sr	1384.0	0.90	0.06	156.66	1.02	4.37	0.17	8.01E + 09	4.33E + 08
134 Te	566.1	0.186	0.01	41.8	0.8	4.41	0.18	8.08E + 09	5.54E + 08
^{135}I	1260.6	0.287	0.009	394.2	1.2	6.71	0.19	7.93E + 09	3.74E + 08
Total Fissions $=$								7.94E + 09	2.30E + 08
						Fissions/	/gram =	7.49E + 11	5.40E + 10
Number of Fissions in the Sample 1+3 (Long time-scale count)									
Isotope	E_{γ} (keV)	Г	unc.	$t_{1/2}$ (h)	unc.	Ref. Y	unc.	N_f	unc.
⁸⁷ Kr	402.7	0.50	0.03	1.2717	0.0083	1.74	0.05	1.99E+10	1.37E + 09
⁹² Sr	1384.0	0.90	0.06	2.611	0.017	4.37	0.17	1.92E+10	1.51E+09
⁹⁹ Mo	739.6	0.122	0.005	65.976	0.024	6.12	0.24	2.02E+10	1.18E + 09
¹³⁵ I	1260.6	0.287	0.009	6.57	0.02	6.71	0.19	1.91E+10	$8.25E{+}08$
					Total F	issions =	1.96E + 10	5.80E + 08	
						Fissions	g/gram =	$7.44E{+}11$	$2.36E{+}10$



Results: 45 Isotopes/Isomers : 191 γ -rays





Results: Investigating Branching Ratios

- Example ¹²⁹Sb: Four γ-rays were observed
 - Three γ -rays give consistent result
 - One is a clear outlier -> Potential issue with branching ratio for this γ-ray?
- Requires further investigation
 - What is ENSDF FPY value based on?
 - Ex. Was it the 761 keV γ -ray?
 - What is the ENSDF branching ratio value based on?
- Potential to improve accuracy of nuclear data
- Highlight areas where future experiments could be focused — Investigate ¹²⁹Sb branching ratios







Conclusion

- Fission product yields have been measured for 45 unique isotopes/isomers
 - Using 191 γ -rays
 - More to come!
 - Currently investigating discrepancies in results (ex. ¹²⁹Sb)
 - Update branching ratios?
 - Take another look at experiments included in the ENSDF evaluation
- Full Results to be published in future Nuclear Data Sheet Article
- Results from this experiment will be compared to FPYs of ²³⁵U, ²³⁸U, ²³⁹Pu, and ²³³U
 - ²³⁵U, ²³⁸U, and ²³⁹Pu irradiations have been completed
 - ²³³U irradiation planned for early/mid 2021
 - Self-consistent FPY results for 5 actinides
 - All irradiations utilized GODIVA
 - All γ -ray count utilized the same experimental setup
 - All data will be analyzed/re-analyzed with the codes developed in this work



Collaborators & Acknowledgements



This work was funded by the Office of Defense Nuclear Nonproliferation Research and Development within the United States Department of Energy's National Nuclear Security Administration.

This work was performed under the auspices of the United States Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.

The National Criticality Experiments Research Center (NCERC), utilized in this work, is supported by the United States Department of Energy Nuclear Criticality Safety Program, funded and managed by the National Nuclear Security Administration for the Department of Energy.



Lawrence Livermore National Laboratory

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

GODIVA Burst



Figures generated by Bruce Pierson



