



University of Birmingham simulations update

P.P. Allport, L. Gonella, P. Ilten, P.G. Jones, P.R. Newman, H. Wennlöf
25th of June 2020




Fun4All – GDML import

- Thanks to Jin, Alexander, and Rey for helping with this
- EICROOT set up to export geometry pieces as GDML files
 - One file for each subdetector part, see next slide
- Possible to import the exact EICROOT geometries used into new framework, thus using EICROOT as a "scripting tool" for easily generating layouts



Fun4All – GDML import





- Bst.gdml Sitpc.gdml TimeStamping.gdml Vst.gdml Fst.gdml
- Beampipe 18 mm radius 0.8 mm thick beryllium, as in EICROOT.
 Study done in central region.
- Set up in a modular way, easy to turn on/off detectors

3

EICROOT benchmarking


- Using a previous study in EICROOT:
 - Export GDML geometry, and import into Fun4All
 - Generate particles in same parameter space
 - Run same analysis code on output
 - Compare results
- All-silicon, varying outer radius study used
 - Details: http://cern.ch/go/xKk6






EICROOT benchmarking – initial results

- Relative momentum resolution studied
- Different outer radii used;
 - 409.8 mm
 - 500.0 mm
 - 600.0 mm
 - 775.0 mm
- No significant difference between results from the different frameworks
- Gives confidence that both old and new studies are relevant



Comparing ITS2-like to ITS3-like


- Comparing sensor technology possibilities in new layout
 - New beampipe
 - 3 inner layers
 - 2 outer layers
 - Gas TPC outside
- ITS2-like:
 - 20x20 µm² pixel size
 - Inner layers: 0.3% X₀
 - Outer layers: 0.8% X₀
- ITS3-like:
 - 10x10 µm² pixel size
 - Inner layers: 0.05% X₀
 - Outer layers: 0.8% X₀




Comparing ITS2-like to ITS3-like

- Parameters used:
 - Particle: π+
 - Transverse momentum range: 0 to 5 GeV/c
 - Pseudorapidity range: -0.5 ≤ η ≤ 0.5
 - Magnetic field: uniform 1.5 T
 - Standard EICROOT gas TPC
- No significant difference in relative momentum resolution

Relative momentum resolution






Comparing ITS2-like to ITS3-like

- Transverse pointing resolution vastly improved using ITS3-like design
- Small pixel size and low material both improve the resolution
- At higher momenta difference is a factor 2, as expected when changing pixel size by a factor of 2

Transverse pointing resolution



Comparison to old baseline

- Checking against the resolution using the "old baseline" and old beampipe (green curve here)
- New beampipe radius degrades pointing resolution, however, using ITS3-like vertexing layers, the resolution is comparable

Transverse pointing resolution

