Update on the Electron Cap-ECAL MC simulation

M. Battaglieri, V. Berdnikov, M. Bondì, C. Fanelli, Y. Furtelova, T. Horn, I. Larin, D. Romanov

Description of the activity

Ultimate goal: Study of the Electron Cap ECAL performance and optimization of the detector


We are working on:

- ★ Implementation of the Electron Cap-ECAL in g4e:
 - Geometry
 - Digitization



- Reconstruction algorithm in EJANA framework Working in progress
- * Analysis plugins in EJANA for study the Electron Cap ECAL performance Working in progress
 - Energy resolution
 - Effect of the Ecal resolution on reconstructed quantities like Q2, x
- ★ Al optimization based on the approach described in https://iopscience.iop.org/article/ Working in progress 10.1088/1748-0221/15/05/P05009/meta

g4e + ejana simulation and recon



A hit in electron endcap calorimeter. Simulated with g4e particle gun


https://gitlab.com/eic/escalate/plugins/calorimetry_studies

MC simulation: geometry

Detector in g4e Credit to D. Romanov

MC simulation: geometry

Electron cap ECAL in g4e



Homogenous calorimeter:

- →Inner part:
 - Rin = 20 cm, Rout = 82 cm
 - PbWO4 crystals: 20 x 20 x 200 mm³
- →Outer part:
 - Rin =85 cm, Rout = 133 cm
 - DSB:Ce: 40 x 40 x 400 mm³

MC simulation: Digitization

Description of the response of a crystal coupled to a SiPM is implemented in g4e, based on the experience gained with CLAS12-FT in HALLB and BDX:

- \odot Estimate of the total deposited energy Etot = ΣE_i
- Estimate the number of photons generated in the scintillator and reached the crystal surface:
 Nγ = Etot * LY
- Estimate the number of photons hitting the sensor surface $N\gamma = N\gamma^*$ (Asensor/Acrystal)
- Estimate the number of photo-electrons Npe taking into account the SiPM saturation effect:
 Npe = Ncells * (1 exp (- Nγ *PDE/Ncells)) (F. Acerbi et al. NiMA 926(2019)16
- Number of pe is extracted randomly according to a Poisson distribution with mean equal to Npe

First results

The response of the inner part (PbWO4 +SiPM) to electrons was evaluated

Crystal:

Material: PbWO4

• Size: 2x2x20 cm³


• LY: 240 γ/MeV

SiPM:


• Area: 1.2 x 1.2 cm²

• pixel pitch: 25 um²


• PDE: 0.22



Energy Resolution



Energy Resolution - CLAS12 FT




Energy resolution in agreement with expected value


Reconstruction algorithm in EJANA framework

Islreco reconstruction algorithms

- The main developer is Ilya Larin. Now the librarty is rewritten to C/C++ and publically available at: https://github.com/emcal/islreco
- Island method clusterization is combined with common reconstruction algorythms
- Can be used for hybrid calorimeters
 (The main author has 20+ years of experience with hybrid calorimeters)
- Has many features. E.g. can receive X,Y coordinates from tracking for better cluster separation and more.
- Used in existing experiments:
 - SELEX (Segmented Large X baryon Spectrometer) Fermilab
 - PrimEx-II (JLab HallB)
 - PrimEx-D (JLab HallD)
 - Many publications based on reconstructions that embedded this library (<u>Fermilab list</u>, <u>JLab list</u>).



HyCal hybrid calorimeter with 1152 PbWO₄ modules 576 Pb-glass modules



Precision measurement of the neutral pion lifetime

American Association for the Advancement of Science By I. Larin, Y. Zhang, A. Gasparian, L. Gan, at all. 2020

Analysis plugins in EJANA

Study the effect of the ECAL resolution on DIS reconstructed quantities:

Electrons multiplicity (based on Beagle data)

events count: 39735

All electrons:

barrel : 24228

e cap : 29006


ion cap : 5503

Recoil only electrons:

barrel : 11945

e cap : 27810


ion cap : 2



Credit to D. Romanov

Analysis plugins in EJANA

Study the effect of the ECAL resolution on DIS reconstructed quantities:



Resolution in Q2 e X related to the angle and energy resolution

- Reconstructed kinematic variables calculated solely from the scattered e- (EM method)
- $\mathbf{Q}^2_{\mathsf{EM}}$ and \mathbf{X}_{EM} are calculate using the e- information (E, $\mathbf{\theta}$) from the tracks no the reconstructed ones (not yet!).

Summary

- ★ Synergy between "R&D on Homogeneous Calorimeter Materials for EIC using Crystals and Glasses" group and EIC Software group
- ★ Implementation of the Electron Cap ECAL in g4e is ready.
- ★ Calorimeter reconstruction will be soon releasing.
- * Analysis plugins under development.
- As soon as the previous items will be completed, the optimization activity based on AI will start