



Need for a preshower in h-endcup?

A.Bazilevsky

YR-Calorimetry TG meeting

Aug 18, 2020





π^0 in SiDLS



May need to measure up to 100 GeV/c and beyond

π^0 in Exclusive DIS

From YR-Exclusive group
Theory calc. (Miami meeting)




May need to measure up to 100 GeV/c and beyond

h-endcup EMCal capability

High granularity/density h-endcap EMCal:
2.5×2.5 cm² granularity at z=3m

Pi0 merging prob vs p




Limited EMCal performance at high p

Significant deterioration at lower rapidity
(for non-projective EMCal)

For projective EMCal, all colored curves
will be at or below the magenta one

Preshower



100 GeV/c π^0
1x1 mm² pixel

Preshower with granularity <3mm would do the job

Two photons from 150 (100) GeV/c π^0 are separated by ~
5.5mm (~8mm) in the EMCal

Also improves photon position resolution and e/h separation

Still a lot of points to clarify

Rapidity coverage

Converter thickness

Number of layers