

MPS upgrade status

Angelika Drees, Phil Dyer, Tustin Gage, Rob Hulsart, Jonathan Laster, Carl Schultheiss,
Matthieu Valette, Jon Sandberg and more



Overview and run 2020 summary

| Component | details | status |
|-------------------------|---|---|
| Delayed aborts | Fully redundant system, 6ms delay, most of run 2020 | ✓ |
| Delayed quench switches | When RHIC abort system is delayed, quench switches are too | ✓ |
| BLM | Considerably tighter limits at all machine modes | ✓ |
| BPM MPS | Selection of 40 BPM per ring continuous logging, high sampling Flexible setup Limits change automatically Included in PM analysis Include more BPMs Incorporate into modeswitch | ✓ ✓ ✓ ✓ ✓ ✗ in progress |
| PS | All 18 alcoves equipped with CPSBPS Service building supplies | ✓, in progress ✗ |
| RF | Enabled to pull permit, no changes to 2019 | ✓ |
| Abort analysis | Abort database Abort by abort analysis 10 kHz, inclusion in PMViewer | ✓ In progress ✓, in progress |

Overview of MPS components

Plenty of progress!! Thanks to LOTS of help from Matthieu, Rob, Jon, Phil and Tustin



Power supplies

Alcoves

- The new and fast system trips when the corrector supply is NOT ON
- It is AT LEAST 20 ms faster than the old system (typically more)
- All alcoves are equipped with the new CPS BPS board
- The system was active in run 2020 but only operated masked
- Still diagnosing occasional communication issues
- Expected to be fully operational in 2021

Service buildings

- CPS BPS system will be expanded to service buildings
- Design will be based on alcove system
 - Needs modifications
 - monitor analogue voltage and current error of each supply
 - Compare to window
- 4 boards per service building would be required
- Test one prototype in run 21 in one service building (1006b?)



- Total of the 36 H + 4 V BPMs per ring
- Each has 4 individual trip limits:
 - Coherence
 - Minimum position
 - Maximum position
 - Difference
- Up to 16 different events to change trip limits are supported
- Shared with the 10 Hz feedback system
- The MPS BPMs have their own (fast) link
- Controlled by dedicated ADOs, one V301 board
- 1 kHz continuous logging of position, coherence and difference
- 10 kHz sampling rate, included in PM analysis

BPM MPS

Brief overview



Summary of all permit trips during run 19 and 20

| | Run 19 total | physics | Run 20_1 total | physics | Run 20_2 total | physics | Total |
|--------------|--------------|---------|----------------|---------|----------------|---------|-------|
| All | 847 | 238 | 492 | 229 | 336 | 146 | 1675 |
| Delayed | 15 | 15 | 29 | 28 | 71 | 69 | 115 |
| BPM MPS | 27 | 11 | | | 27 | 23 | 54 |
| Abort Kicker | 13 | 3 | 21 | 12 | 51 | 10 | 85 |
| PS main | 37 | 2 | 18 | | 33 | 1 | 88 |
| PS | 2 | 1 | 9 | 3 | 3 | 2 | 14 |
| BLM | 369 | 187 | 300 | 191 | 122 | 91 | 791 |
| Quench | 17 | 8 | 16 | 12 | 6 | 3 | 39 |
| RF | 218 | 22 | 95 | 9 | 64 | 7 | 377 |
| Vacuum | 4 | | 3 | | 7 | 3 | 14 |
| STAR | 5 | | 1 | | 6 | 3 | 12 |
| LEReC | 129 | 2 | 25 | 1 | 5 | | 159 |
| CeC | | | 3 | 1 | 8 | 2 | 11 |



RHIC BPM MPS trips

- ❖ Fast BPM input was active but masked for most of the run
- ❖ Enabled and unmasked:
 - ❖ Aug 18 - Sept 1
 - ❖ fill #28453 to #28785 (span of 332 fills)
 - ❖ not engaged during CeC fills (due to ramping)
 - ❖ 27 permit pulls/aborts during those 14 days:

| Testing | injection | Bad reading | noise | Setup | BTF or bump | Wrong attribution | Protective dumps |
|-----------|--------------|---------------|---------------|------------|-------------------|---------------------|------------------------------|
| 2 | 6 | 4 | 2 | 3 | 5 | 1 | 4 |
| voluntary | Event timing | Ignore count? | Low intensity | Procedure? | After ev-lumi-off | Postmortem analysis | Quench, coherence or 10Hz FB |



RhicBpmThreshold application

Similar to RhicLossThreshold

Contains a set of tables for blue and yellow BPMs

File shown here is:

Au20-5GeV.bpmmps.old

Which file is used can be found (and set) in SSOP -> **Expert only** activity to change that file!


Handles up to 16 events with varying sets of limits.

Shown here are the limits for event2 = ev-lumi

The number and order of events will vary from file to file

Units are micron

Permit input needs to be enabled in BisConfig



| | Input Channel | Permit dropped | Loss Monitor | Prefire | PS Faults | QLI (B Y) | Ramping (B Y) | Ion (B Y) | Blue Energy (GeV/n) | Yellow Energy (GeV/n) | Blue Intensity (1E9 Ions) | Yellow Intensity (1E9 Ions) | |
|----|---------------------|----------------|--------------|---------|-----------|-----------|---------------|-----------|---------------------|-----------------------|---------------------------|-----------------------------|--------------------------------|
| | Loss Monitor 1 | 10a-ps3.A | y9-lm4 | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 85.3504 | 127.216 | ? |
| er | Yellow Abort Kicker | 10a-ps3.B | | No | No | No No | Yes Yes | Au Au | 1.79546 | 1.79554 | 0.0 | 0.0 | ? |
| | BPM Yellow | 2a-bcm1 | | No | No | No No | Yes Yes | Au Au | 21.69895 | 21.69868 | 0.000237848 | 14.0663 | ? |
| | RF Blue | 4a-bsyn | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00140211 | 0.0 | ? |
| | BPM Yellow | 2a-bcm1 | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 42.9104 | 42.9973 | ? |
| | RF Yellow | 4a-bsyn | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00130612 | 0.0 | ? |
| | Loss Monitor 1 | 7w-ps2.A | g6-lm8 | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00190796 | 0.0 | ? |
| | Loss Monitor 1 | 5e-ps2.A | g5-lm7.2 | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.0041707 | 0.0 | ? |
| | Loss Monitor 1 | 5e-ps2.A | g5-lm7.2 | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00262689 | 0.0 | ? |
| | BPM Blue | 2a-bcm1 | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 11.3203 | 32.996 | ? |
| er | Yellow Abort Kicker | 10a-ps3.B | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00128504 | 0.0 | ? |
| | BPM Yellow | 2a-bcm1 | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00154908 | 0.0654334 | Coherence trip |
| | Loss Monitor 1 | 5e-ps2.A | g5-lm9.2 | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 139.579 | 126.644 | Trip of g5-lm9 tripped the BP |
| | BPM Yellow | 2a-bcm1 | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 0.00184707 | 18.1022 | Coherence trip |
| | BPM Blue | 2a-bcm1 | | No | No | No No | No No | Au Au | 4.59257 | 4.59257 | 14.8538 | 18.5945 | Fourth on mar the reflection c |

Abort database

- Appends semi-automatic
- 2019 and 2020 data included



Setup View Help

Select System

- Booster
- AgS
- RHIC
 - PowerSupply
 - LossMonitor
 - XFMR
 - BPM**
 - Quench-Permit
 - RF
 - RomanPot

Run Name: run_fy20

Data Source: Feedback

Time Period: Last day

Ring: Both

Initiated By: Yellow Trigger

View: By BPM

| Name | Date | Fill Num | Comment |
|---------|---------------------|----------|--|
| rhicbpm | Sat Aug 29 01:50:43 | 28703 | RHIC Yellow BPM Internal Trigger Generated Event save - da |


Read And Plot

Reading files - please be patient...
 File found for event type - yd
 Change 'Initiated by' to 'All' and look for another event at the same time - Fri Aug 28 11:55:15 2020
 Some post mortems successfully displayed, some had problems?

PostMortem analysis

- Two Data sources:
 - PostMortem
 - Feedback
- Post Mortem
 - Shows about 100 ms of 10kHz data from the MPS BPMs
 - Time axis is wall clock time
 - Allows you to add abort and abtkick events
- Feedback
 - Same 100 ms of 10kHz data
 - Same subset of BPMs
 - Time axis is seconds from ev-abort





Data source PostMortem

Summary panel

Expanded graph

Markers can be added from “Plots”
menu in the top

ev-abort and ev-abtkick are different
by 6ms = delayed abort



SetupView

Select System

Booster

Ags

RHIC

PowerSupply

LossMonitor

XFMR

BPM

Quench-Permit

RF

RomanPot

Run Name: run_fy20

Data Source: Feedback

Time Period: Beam abort

Ring: Blue dump

Initiated By: Yellow dump

View: Blue Trigger

| Name | Date | Fill Num | Comment |
|----------------|----------------------------|--------------|----------------------------|
| rhicbpm | Tue Aug 25 10:23:49 | 28633 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 09:41:17 | 28632 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 09:19:57 | 28632 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 09:10:33 | 28632 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 08:36:55 | 28631 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 05:51:08 | 28627 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 01:39:11 | 28621 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 25 00:03:49 | 28620 | RHIC Yellow BPM Int |
| rhicbpm | Mon Aug 24 01:26:39 | 28604 | RHIC Yellow BPM Int |
| rhicbpm | Sun Aug 23 11:15:23 | 28585 | RHIC Yellow BPM Int |
| rhicbpm | Fri Aug 21 14:56:09 | 28536 | RHIC Yellow BPM Int |
| rhicbpm | Thu Aug 20 03:34:11 | 28496 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 20:18:11 | 28492 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 16:01:47 | 28492 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 15:05:05 | 28491 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 13:39:27 | 28491 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 11:28:28 | 28491 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 10:03:04 | 28490 | RHIC Yellow BPM Int |
| rhicbpm | Wed Aug 19 09:04:05 | 28489 | RHIC Yellow BPM Int |
| rhicbpm | Tue Aug 18 10:48:48 | 28465 | RHIC Yellow BPM Int |
| rhicbpm | Mon Aug 17 17:42:10 | 28451 | RHIC Yellow BPM Man |
| rhicbpm | Mon Aug 17 06:34:07 | 28449 | RHIC Yellow BPM Int |
| rhicbpm | Mon Aug 17 03:09:56 | 28445 | RHIC Yellow BPM Int |
| rhicbpm | Sun Aug 16 15:44:01 | 28432 | RHIC Yellow BPM Int |
| rhicbpm | Sun Aug 16 11:03:01 | 28427 | RHIC Yellow BPM Int |

Data source FeedBack

Allows you to select
“Initiated By”


List of files will be different
depending on what you
select

Shown here is Yellow Trigger




Post Mortem Data analysis (every 8th turn, 10 kHz)

Abort during 10HzFB failure 08/20




Abort during CeC ramp 08/27



Summary page, failed input highlighted, data plot can be expanded (next slide)






Expanded Graph

- All three categories of data shown:
 - absolute position
 - difference
 - Coherence
- Event 2 is the 2nd event in the list (see RhicBpmThreshold)
 - This might change to event name later
- All limits (from that event) are added
- t=0 is ev-abort





PM analysis of 10Hz FB failure 08/20

Beam intensity 720 Hz data

Beam position: 10 kHz (every 8th turn)

Individually set limit (here -8 mm)

Very fast amplitude increase:

6ms from 0 to -14 mm

4.59 GeV (very low rigidity beam)

Driven by 10Hz FB supplies

Abort event is triggered at $t=0$ s

Abort kickers are fired at $t = 0.006$ s

NO BEAM left when abort kickers
fired

=> Need to monitor 10Hz supplies

SUMMARY

- BPM MPS ready for use during a physics run
 - Individual trip limits
 - Flexible with changing beam modes
 - should add more vertical BPMs to the system
 - Needs careful procedures to avoid trips after mode switches
- New tools developed to analyse individual aborts and gather statistics
- All alcove PS included in CPS BPS
 - Needs to be operated without masking in run 2021
 - Needs to be upgraded to include service building PS (35-40 per building)
 - One proto type to be tested in run 2021
- we are preparing a tech note to summarize our experience
 - We shall be able to conclude if we are ready for sPHENIX after checking the available data

