

Dual-RICH simulations (Update)

Alessio Del Dotto

for the EIC PID RICH meeting


10-19-2015

Outline

Dual RICH mirror-lens configurations:





- Configuration with double spherical mirror (slides 4-6)
- Configuration with Spherical mirror + Fresnel lens (slides 5-12)

Towards a realistic mirror-lens configuration







- A 2D optical ray tracing software has been developed (based on C++/Root)
- The reflection of the Cherenkov photons can be simulated for different radiators and different mirror configurations
- First approximation of a Fresnel lens has been added
- The photon-detector position can be studied in relation to the focal plane

Thickness of the Aerogel = 4 cm, 4+4 photons generated 1 each cm in the Aerogel




Good photons collection, some problem with the extremal angles

4+4 photons generated 1 each 35 cm in the CF₄ gas




Good photons collection

Focal plane (curve in 2D) --> straight lines interception points




Fresnel lens – possible orientation

We can try to add a Fresnel lens after the Aerogel --> focusing of light and filtering of the UV light







Fresnel lens --> orientation 1







Fresnel lens --> orientation 2


Thickness of the Aerogel = 4 cm, 4+4 photons generated 1 each cm in the Aerogel






Thickness of the Aerogel = 4 cm, 4+4 photons generated 1 each cm in the Aerogel



Lens with higher radius --> less curvature, probably a good direction to explore




Fresnel lens 1






Good photons collection: loss minimized

Lens with higher radius --> less curvature, probably a good direction to explore







Fresnel lens 2



Good photons collection: loss minimized

No problem with the CF₄ gas after the Fresnel Lens



Comments and next developments

- Mirror + mirror configuration: promising solution → at extremal angles part of the Aerogel photons are lost, for the rest the photons can be collected in a detector plane.
- Fresnel lens + mirror configuration: promising solution → the problem with extremal photons is partially solved, almost all the photons can be collected. Additional complexity from the lens.
- Next steps:
 - Try to optimize again the geometry
 - A first estimation of the effective N_{pe} → QE, reflectivity of the mirror, absorption coefficients (radiators, lens)