

GenFit2: Test RKTrackRep

Jin, Xiaorong, Haiwang

Mar. 22, 2016

Outline

Speed Up!

- Discussed with Jin. We decided to use RKTrackRep built in with the current release of GenFit2.
- RKTrackRep is mature and used in many experiments.
- The sPHENIX geometry could be ported to TGeo.
- Can run G4 simulation and RKTrackRep simultaneously.


RKTrackRep:

- Developed for PandaRoot, and have been used in several experiments: . Belle II, PANDA, SHiP, AFIS, GEM-TPC, FOPI, ...
- Use TGeometry to describe the detector
- Propagate through magnetic field: Runge-Kutta method
- Material effect (energy loss, multiple scattering, etc.): GenFit's own calculation.


Today's Topic: Test RKTrackRep.

- Material effect
- Propagate through magnetic field
- Fitter test: Pull, residual.

Multiple scattering



4 station Pb
2cm thick each



$$\theta_0 = \frac{13.6 \text{ MeV}}{\beta c p} z \sqrt{x/X_0} \left[1 + 0.038 \ln(x/X_0) \right]$$

$$y_{\text{plane}}^{\text{rms}} = \frac{1}{\sqrt{3}} x \theta_{\text{plane}}^{\text{rms}} = \frac{1}{\sqrt{3}} x \theta_0 ,$$

2cm Pb, 10 GeV mu+	Calculation	Geant4e
θ_0	0.0027	0.0026
y_0 / cm	0.0031	0.0030

2cm Pb, 10 GeV mu+	Calculation	RKTrackRep
θ_0	0.0027	0.0029
y_0 / cm	0.0031	0.0033

2cm Si, 10 GeV mu+	Calculation	RKTrackRep
θ_0	0.00059	0.00066
y_0 / cm	0.00068	0.00076

Propagate through magnetic field, 2 Tesla, in vacuum

Initial State (0 cm): 10 GeV μ^+


```
3D position: TVector3 A 3D physics vector (x,y,z)=(0.000000,0.000000,0.000000)  
3D momentum: TVector3 A 3D physics vector (x,y,z)=(0.000000,0.000000,10.000000)
```

Final State (10 cm)

```
3D position: TVector3 A 3D physics vector (x,y,z)=(0.000000,0.029980,10.000000)  
3D momentum: TVector3 A 3D physics vector (x,y,z)=(0.000000,0.059958,9.999820)
```

Calculated $p_y = 0.06$ GeV

The data structure of GenFit2, `genfit::Track`




Fitter Test: Procedure

- Setup TGeo detector
- Initialize a μ with pos, mom
- Construct genfit::Track
 - Create measurements:
 - Construct RKTrackRep **rep_true** with true pos,mom
 - Give an arbitrary detector resolution (0.1cm)
 - Propagate **rep_true** to detector plane to get hit
 - Smear hit with resolution.
 - Create TrackRep: **rep_fit**
 - Smear true initial state as seed
- Do the fit.
- Extrapolate **rep_fit** to plane $z = 0$. And calculate pull, residual


Fitter test: detector setup

z plane detectors, 50 μ m Si



B: 2T

μ : (0,0,0)cm; (0,0,1)GeV



GenFit Event Display:

Smoothed track: weighted average between forward fit and backward fit

Yellow: measurement uncertainty $\times 10$

Measurement Types






$m_k = H_k \tilde{x}_k + v_k$	Hit coordinates vector (can be one-dimensional). Hits are counted with the index k .
\tilde{x}_k	The (unknown) <i>true</i> state vector.
H_k	Linear transformation from the vector space of state vectors to the vector space of detector measurements, i.e. m_k and $H_k \cdot \tilde{x}_k$ are in the same coordinate system. The matrix has the dimension $\dim(m_k) \times \dim(\tilde{x}_k)$.
v_k	Deviation or noise of the position measurement.

Measurement Type:






Space Point: TPC
Planar: Silicon
Wire: Drift Chamber

```
const TMatrixD& HMatrixUV::getMatrix() const {  
    static const double HMatrixContent[2*5] = {0, 0, 0, 1, 0,  
                                                0, 0, 0, 0, 1};  
}
```


Pull distribution




Residual



Summary

- Switched to RKTrackRep for now for speed and robustness.
- Leaning and testing GenFit2 with RKTrackRep
 - Material effect
 - Fitter statistical test
- Next step:
 - Real-world test with simplified sPHENIX detector.

Backups



Outline

- Discussed with Jin. And we decided to use RKTrackRep built in with the current release of GenFit2.
 - RKTrackRep is mature and used in many experiments.
 - The sPHENIX geometry could be ported to TGeo.
- Test RKTrackRep



- ▼ 📁 trackReps
 - ▼ 📁 include
 - ▶ 📄 AbsMaterialInterface.h
 - ▶ 📄 DetectorConstruction.h
 - ▶ 📄 G4eTrackRep.h
 - ▶ 📄 G4GFCnv.h
 - ▶ 📄 MagField.h
 - ▶ 📄 MaterialEffects.h
 - ▶ 📄 RKTools.h
 - ▶ 📄 RKTrackRep.h
 - ▶ 📄 StepLimits.h
 - ▶ 📄 TGeoMaterialInterface.h
 - ▼ 📁 src
 - ▶ 📄 DetectorConstruction.cxx
 - ▶ 📄 G4eTrackRep.cc
 - ▶ 📄 G4GFCnv.cxx
 - ▶ 📄 genfitG4eLinkDef.h
 - ▶ 📄 MagField.cxx
 - ▶ 📄 MaterialEffects.cc
 - ▶ 📄 RKTools.cc
 - ▶ 📄 RKTrackRep.cc
 - ▶ 📄 StepLimits.cc
 - ▶ 📄 TGeoMaterialInterface.cc
 - ▶ 📄 trackRepsLinkDef.h

