


# EMCal Skin, Block and Screen Design

Dan Cacace

# EMCal Tolerances and Gaps

2

From Each Face to Nominal		Tolerance		Gap
Between Blocks		$\pm 0.005$ in		0.0075 in
(mm)		$\pm 0.127$ mm		0.1905 mm
Between Blocks and Skin (in)		N/A		0.0075 in
(mm)		N/A		0.1905 mm
Between Skins (in)		$\pm 0.005$ in		0.0625in
(mm)		$\pm 0.127$ mm		1.5875 mm





1/31/2017






# EMCal Blocks

- Constrain the bottom length to have the same value. (Yes?)
- Block tolerance.  $\pm 0.01$  in ( $\pm 0.25$  mm)
- Gaps between blocks. 0.015 in (0.381 mm)
- Gaps between the skin and the blocks. 0.015 in (0.381 mm)
- Gaps between bottom/top of the blocks. Min  $\sim 0.02$  in (0.51 mm)



# EMCal Modules Focus


- Distance from the center of the EMCal to the focal point of the blocks.
  - Axially. Max ~ 0.27 in (6.86 mm)
  - Point to Point. Max ~ 0.36 in (9.14 mm)
  - Radially. Max ~ 1.02 in (25.91 mm)





# EMCal Modules Focus


- Axially and point to point can be adjusted slightly by changing the geometry of the blocks and no change to the gaps.
- Creating a angled gap between skins, and thus adjusting the block geometry accordingly, would eliminate the radial gap. (0.55 deg.)
- Max gap increase:  $0.0414 * 2 = 0.0828$  in (2.1031 mm)



# EMCal Screens

7



- How far into the block should the first/last screen be? (6 mm?)
- Area for the triangles created by the center to center lines within a block constrained to be equal. (Yes?)
- Triangle area compared to the “ideal area” max percent error. ( $\pm 0.7\%$ ).





# EMCal Screens

8



B\*H = Number of Fibers:  
(CTC-Diameter)-Tolerance  
= Gap

47\*52 = 2444 Fibers:  
(0.9689-0.7)-0.2032  
= 0.0657mm or 0.0026"

47\*53 = 2491 Fibers:  
Same as above.

48\*53 = 2544 Fibers:  
(0.9485-0.7)-0.2032  
= 0.0453 mm or 0.0018"

48\*54 = 2592 Fibers:  
Same as above.

49\*54 = 2646 Fibers:  
(0.9290-0.7)-0.2032  
= 0.0258 mm or 0.0010"

49\*55 = 2695 Fibers:  
Same as above.

49\*56 = 2744 Fibers:  
Same as above.

50\*56 = 2800 Fibers:  
(0.9102-0.7)-0.2032  
= 0.007mm or 0.0003"

51\*56 = 2856 Fibers:  
(0.8922-0.7)-0.2032  
= Negative

47\*53 = 2491 Fibers:  
(0.038-0.0.28)-0.008  
= 0.002" or 0.0508 mm

48\*54 = 2592 Fibers:  
(0.037-0.0.28)-0.008  
= 0.001" or 0.0254 mm


49\*56 = 2646 Fibers:  
(0.037-0.0.28)-0.008  
= 0.001" or 0.0254 mm

50\*56 = 2646 Fibers:  
(0.036-0.0.28)-0.008  
= 0.000"



# EMCal Block 24 Drawing


9



1/31/2017

# EMCal Typical Screen Drawing

10




1/31/2017




# EMCal Aluminum Skin / Box Rails

- One set of rails, aluminum.
- Bearing block, zinc, aluminum or 316 stainless steel.
- Rail width. 6 in (154.4 mm)
- Rail height. 0.7 in (18 mm)



# EMCal Aluminum Skin / Box Rails






12








1/31/2017



# EMCal Dimensions



# EMCal Dimensions





# EMCal Dimensions

