




# BNL EMCAL Mold Designs



# 2 DIFFERENT MOLD DESIGNS




## DISSOLVABLE MOLD

Made from PVA filament  
Dissolvable in water

## MACHINABLE MOLD


Easily machinable  
“Digital ABS”



# EMCAL Machinable Mold




FILLED WITH TUNGSTEN EPOXY – NO FIBERS YET






# HCAL Light Collection Current




1" Endmill

- Mold clamped in place
- Block tilted in mold
- Machined in ~8min.

# HCAL Light Collection Proposals




- Mold is flipped to machine 3 sides
- Removed from vise






# EMCAL Machinable Mold



Separate 3D Printed clamps are then used to machine final side

# EMCAL Dissolvable Mold



Dissolvable mold is printed from PVA filament and inserted into an aluminum box for stiffening.



# EMCAL Dissolvable Mold




Filled with a pre-mix of tungsten powder and epoxy.

Mold is removed for aluminum box and placed into a warm bucket of water for a few hours. The mold is then peeled away and cleaned up.






# EMCAL Mold Designs



Accuracy of machinable mold can be made better ( $\pm 0.005$ ).

Dissolvable mold is actually better than  $\pm 0.005$ . We measured to  $\pm 0.002$ .

# EMCAL Mold Designs – Next Step



Print dissolvable mold with  
2x2 screens.

Print machinable mold with  
2x2 screens.