Large area GEM tracking

Kondo Gnanvo

University of Virginia, Charlottesville, VA

fsPHENIX Workshop, Iowa State Univ. March 12, 2016


Outline

- ✓ Basics of GEM detectors
- ✓ Large area GEM
- ✓ Large GEM R&D in US
- ✓ RD51 Collaboration



Basics of GEM detector: GEM Foil as Electron Amplification

- Thin, metal-clad polymer foil chemically perforated by a high density of holes, typically 100/mm²
- Voltage of ~ 350 V across the Cu electrode creates a strong field in the hole leading to amplification
- The ionization pattern is preserved by design with the electric field focusing the charges inside the holes




F. Sauli, Nucl. Instr. and Meth. A386(1997)531


UNIQUE FEATURE

Charge amplification is decoupled from the charge collection ⇒ Multi stage amplification




Basics of GEM Detectors: Performances






Timing resolution




Position resolution



Basics of GEM Detectors: The COMPASS Triple-GEM Design

- 3 GEM foils with cascade amplification
- ~ 350 V across the foil ensure an average gain per foil of 20 to 25
 - ✓ Low discharge probability
 - ✓ Electric field ⇒ focus electrons to the holes better spatial resolution
 - ✓ Structure minimize electron flow back
 - ✓ Flexibility of the electron collection structure and readout design.



COMPASS @ CERN first use of GEM in HEP Experiment

Large Area GEM



Large Area GEM: Single Mask Technique





Figure 1. Schematic comparison of procedures for fabrication of a double-mask GEM (left) and a single-mask GEM (right).

Progress on large area GEMs Serge Duarte Pinto et al., JINST, November 26, 2009, [http://arxiv.org/pdf/0909.5039v2.pdf]




Large Area GEM: NS2 Assembly Technique

pioneered by CMS GEM Muon Upgrade collaboration & RD51




- Mechanical stretching with small frames with the use of a set of screws, fittings for the stretching
- Control of the stretching and the flatness of the GEMs
- No glue involved in the assembly
 Chamber can be re-opened
- No need for spacers in active area
- BUT: Lots of screws and rigid supports material critical for tracking detectors

Close view of 3 GEM stack with NS2 technique




CMS GE1/1 NS2 detector assembly




Rui De Oliveira, CERN PCB workshop

Large Area GEM for Tracking

PRad GEMs (JLab, USA)



CBM MUCH (FAIR, Germany)



CMS GEM (CMS, CERN)






Large GEM R&D in the US



Large GEM in US: University of Virginia GEM R&D

Storage of the frames



Frames holder for cleaning




Ultra sonic bath (USB)




 $(3 \times 7 \text{ m}^2)$ Class 1000 Clean Room



Storage of the framed foils



Glue dispenser




Tacky roller → dust removal



Large GEM in US: University of Virginia GEM R&D

Large cosmic test bench

University Virginia



Large GEM in US: University of Virginia GEM R&D

- 29 modules (60 x 50 cm²) built @ UVa
- All the 29 modules passed the final test
- 16 more in the next 12 months

SBS GEMs currently stored at UVa





Large GEM in US: Temple University GEM R&D

- Major effort on STAR Forward GEM Tracker completed with full installation in fall 2012 24 large triple-GEM detectors arranged on disks / 30720 channels (APV25-S1)
- Large group at TU with fully equipped micro-pattern detector laboratory (Detector lab and permanent clear room facility) at new
 Science Education and Research Center with outstanding resources
- Major funded EIC R&D effort on large triple-GEM detectors focusing on light-weight structures and commercial fabrication of various detector components

New Laboratory facilities at Temple University

GEM Clean Note: Room (a/b) is ready (Move-in soon) / GEM detector (c/d/e) lab move-in completed. will Both labs be equipped with new **Newport Optical tables** (6'x4') provided **Temple** University, CST (Cost: \$25k)


















Large GEM in US: Temple University GEM R&D

Single mask GEM Foil: CCD scan setup


- ✓ 2D scanning table with CCD camera fully automated
- ✓ Scan GEM foils to measure hole diameter and pitch
- ✓ Unique world-wide setup in micro-pattern detector
- Critical for feedback in development and QA stage!







Inner Hole Diameter




- Inner hole diameter and pitch are compared between a Tech-Etch and CERN (Only 1 CERN foil has been optically scanned) single-mask 10 X 10 cm² foil.
- Mean inner hole diameters between the two foils are similar size.
- The mean pitch between the two foils is also have similar values.
- However a double peak structure is present in the CERN pitch distribution.



GEM in Experiments: @ JLab


GEM Trackers, Super BigBite Spectrometer (SBS), hall A SBS physics program


- ➤ **GEP** : 12 (GeV/c)²
- ➢ GMN: 13.5 (GeV/c)² ➤ GEN: 10 (GeV/c)²
- SSA in nSIDIS: 30,000 gain vs HERMES
- A1n/d2n gain ~ 20-30 compared with HMS/SHMS
- > TDIS meson DIS
- ➤ WACS-ALL, full proposal, 100x gain in productivity
- > GEnRP, ready for full proposal, 10+x gain in productivity
- \triangleright pol H(γ , φ p), H(γ , π ° p)
- > PVDIS gain 10-15 compared with two HRSs
- \rightarrow A1p/d2p gain ~20-30
- ➤ D(e,e'd) A,T20
- ➤ J/Psi as gluon probe of QCD well matched to BB/SBS
- \triangleright A(e,e'p), A(e,e' $\pi^{+/-}$)





GEM radial TPC, BoNUS, hall B






proton / deuteron / 3He / 4He


H. Fenker, JLab





Specifications:


- 2 chambers: total active area: (122x110 cm²), COMPASS readout
- factor of >10 improvements in coordinate resolutions
- similar improvements in Q2 resolution (very important)
- unbiased coordinate reconstruction
- increase Q2 range by including Pbglass part






GEM in Experiments: @ BNL

Forward GEM Tracker (FGT), STAR



B. SurrowAGS-RHIC Users Meeting,
Workshop Upton, NY, 05/27,
2008



- STAR FGT GEM: 6 triple GEM disks around the beam
 - Each disk: ID~7cm, OD ~40 cm
 - 4 quarter section, ~ 0.14 m² each

Hadron Blind Detector (HBD), PHENIX


GOAL:


Detect double e- hits (signal) from e- from γ (background) HDB close to the beam pipe


- ⇒ Cerenkov blobs from two leptons = 2 pads
- □ Cerenkov blobs for single electron = 1 pad

BUT:

Detector should be insensitive to hadrons










Large GEM R&D




Large GEM R&D: Forward Tracking for Future Projects


EIC Detector Conceptual design

fsPHENIX Detector Conceptual design






SoLID Conceptual design



Rate: 100 to 600 kHz/cm² (with baffles), GEANT4 estimation Spatial Resolution: \sim 100 μ m (sigma) in azimuthal direction Total area: \sim 37 m² (30 sectors x 5 planes)



Large GEM R&D: Forward Trackers in the Future Projects




Florida Institute of Technology (FIT)

- Recently submitted a results of their large area (~1 m) triple-GEM detector to NIM A for publication.
- Successfully used zig-zag readout as a means to maintain good sp atial resolution while reducing number of readout channels needed
- σ_{φ} = 193 µrad


NIM A 811 (2016) 30-41


Temple University (TU)

- Have been working with US company Tech-Etch towards commercializing la rge-area GEM foils.
- Recently published results of electrical and geometrical foil quality



NIM A 802 (2015) 10-15





NIM A 808 (2016) 83-92

University of Virgina (UVa)

- Recently published results on their large-area (~1
 - m)/ light weight triple GEM detector
- The detector successfully implemented 2D stereo -angle (U-V strips) readout
- $\sigma_{\rm r} = 550 \, \mu {\rm m}, \, \sigma_{\rm o} = 60 \, \mu {\rm rad}$




Large GEM R&D: U-V Strips readout studies


EIC-FT-GEM (SoLID) Prototype I

- Trapezoid shape 1-m long triple-GEM (3-2-2-2): widths at the inner radius and outer radius equal to 23 cm and 44 cm respectively.
- Readout board: flexible 2D U-V strip readouts (COMPASS style) with a pitch of 550 μm, top layer (140 μm, wide U-strips) run parallel to one radial side of the detector and bottom layer (490 μm, V-strips) run parallel to the other side.
- Test beam results published in NIM A 808 (2016) 83-92


Efficiency vs. HV




Cluster size vs. HV




Distribution of the strip pedestal noise






U-V strip Readout of EIC-SoLID GEM Proto I




Position resolution in x (radial) and y (azimuthal) on various locations on the chamber



Large GEM R&D: Zigzag Strips readout studies

Aiwu Zhang





Motivation: due to large strip width and special structure of the zigzag r/o strips, cluster positions are not anymore accurate if we simply use the Center of Gravity (COG) method.

Method: we correct 2-strip and 3-strip clusters' positions separately using tracking information. We define $\eta \stackrel{\text{def}}{=} s_a - s_{max}$ for each event. s_a is position from normal COG method, s_{max} is the strip number on which max. charge is collected. η-dependent response functions are obtained, and corrections are made based on these functions.

Position resolution

NIM A 811 (2016) 30-41






Position scan at 3200V


HV scan at at Position 1


Large GEM R&D: Common GEM foil design for EIC

(UVa, Florida Tech, Temple U.)



- -> <u>Foil width</u> (at the large R end) is limited to **560** mm due to material limit of 610 mm (25 mm margin is needed for foil production).
- -> A <u>trapezoid</u> foil with a length of **903.57 mm**, widths at both ends of **43 mm** and **529 mm** (for the active area).
- -> Opening angle of the trapezoid is **30.1 deg**., allows some overlap when making a disk from 12 same type detectors.
- -> Active area is divided into <u>8 HV sectors in R</u> direction at inner R and <u>18 HV sectors in azimuthal</u> directions at outer R. This allows to reduce discharge energy if happens. Each sector ~100 cm² and gaps between sectors are 0.1 mm.
- -> HV connections are to be made from the large R end.





Zigzag strips readout


No.	Strip type	No. of strips	Angle pitch (mrad)	Length of sector (cm)
1	Straight	128	4.14	12
2	Zigzag	128	4.14	12
3	Zigzag	384 (=128*3)	1.37	22
4	Zigzag	384	1.37	22
5	zigzag	384	1.37	22

- divide the r/o area into 5 sectors and use straight strip in the innermost sector.
- Total number of channels is 1152(=128*9),
 9 APVs will be needed to read out the full detector lower electronic cost
- Only 1D position information
- Lower position resolution

IEEE NSS/MIC 2015, A. Zhang





-> Type A has been tested in our previous prototype (arXiv:1508.07046), type B will be chosen for the next prototype. The reason is: type B design gives better charge sharing and shows less non-linear response.




2D strips in R and φ coordinates.

- 2D position information
- Good position resolution













MT6-2A 3-coordinate readout

D. Majka, Yale U.



Standard Cartesian Readout

- "Compass Style"
- XY Hit Matching by Charge



New 3-coordinate Readout
-Hit matching: GEOMETRY & CHARGE

Challenge:

Cartesian Readouts can lead to ambiguities in X-Y associations for high multiplicity events.

- **□** Solution:
 - 3 coordinate readout made on double-sided kapton.
- ☐ Goal:

Increased tracks per "patch" reduces channel count.




EIC GEM R&D: Low Mass Material R&D

Cr-GEM foil:

- ✓ Copper (Cu) clad raw material comes with 100 nm Chromium (Cr) layer between Cu and Kapton, 5µm Cu layers removed, leave only 100 nm residual Cr layers as electrodes, Cr-GEM foils provided CERN PCB workshop
- ✓ Using Cr-GEM foil lead to almost 50% reduction of the material of an SoLID-like light weight triple-GEM detector: this is because the material in a lightweight triple-GEM is dominated by the GEM foils & readout board

Standard GEM






100 nm Cr 50 μm Kapton

Lower material of GEM foil (UVa)

Exploded 3D View



RD51 Collaboration



RD51 Collaboration




RD51 Collaboration Development of Micro-Pattern Gas Detectors Technologies



The proposed R&D collaboration, RD51, aims at facilitating the development of advanced gas-avalanche detector technologies and associated electronic-readout systems, for applications in basic and applied research. The main objective of the R&D programme is to advance technological development and application of Micropattern Gas Detectors.

The invention of Micro-Pattern Gas Detectors (MPGD), in particular the Gas Electron Multiplier (GEM), the Micro-Mesh Gaseous Structure (Micromegas), and more recently other micro pattern detector schemes, offers the potential to develop new gaseous detectors with unprecedented spatial resolution, high rate capability, large sensitive area, operational stability and radiation hardness. In some applications, requiring very large-area coverage with moderate spatial resolutions, more coarse Macro-patterned detectors, e.g. Thick-GEMs (THGEM) or patterned resistive-plate devices could offer an interesting and economic solution. The design of the new micro-pattern devices appears suitable for industrial production. In addition, the availability of highly integrated amplification and readout electronics allows for the design of gas-detector systems with channel densities comparable to that of modern silicon detectors. Modern wafer post-processing allows for the integration of gas-amplification structures directly on top of a pixelized readout chip. Thanks to these recent developments, particle detection through the *ionization of gas* has large fields of application in future particle, nuclear and astro-particle physics experiments with and without accelerators.

The RD51 collaboration involves ~ 450 authors, 75 Universities and Research Laboratories from 25 countries in Europe, America, Asia and Africa. All partners are already actively pursuing either basic- or application-oriented RB0 involving a variety of MPGD concepts. The collaboration established common goals, like experimental and simulation tools, characterization concepts and methods, common infrastructures at test beams and irradiation facilities, and methods and infrastructures for MPGD production.



World-wide coordination of the research in the field to advance technological development of Micropattern Gas Detectors

- Foster collaboration between different R&D groups; optimize communication and sharing of knowledge/experience/results concerning MPGD technology within and beyond the particle physics community
- Investigate <u>world-wide needs</u> of different scientific communities <u>in the</u> MPGD technology
- Optimize R&D financing by creation of common projects (e.g. technology and electronics development) and common infrastructure (e.g. test beam and radiation hardness facilities, detectors and electronics production facilities)
- The RD51 collaboration will <u>steer ongoing R&D activities</u> but <u>will not direct</u> the effort and direction of individual R&D projects
- Applications area will benefit from the technological developments developed by the collaborative effort; however the responsibility for the completion of the application projects lies with the institutes themselves.

RD51 Collaboration Webpage

http://rd51-public.web.cern.ch/RD51-Public

RD51 Conference Contributions, Seminars

http://rd51-public.web.cern.ch/RD51-Public/Documents/ConferenceContributions.html http://rd51-public.web.cern.ch/RD51-Public/Documents/Seminars.html


Copyright CERN 2010 - RD51 webmasters

hop, Iowa State Univ, March 12, 2016

RD51 Collaboration: Around the World

The main objective: advance MPGD technological development & associated electronic-readout systems, for applications in basic and applied research" http://rd51-public.web.cern.ch/rd51-public





Access to the MPGD "know- how"


Foster Industrial Production

VIRGINIA

National and International Laboratories

National Institutes and Universities

RD51 Collaboration: Working Groups



RD51 Collaboration: Highlights & Achievements (2008-20015)

- Consolidation of the Collaboration and MPGD community integration (>80 Institutes, >400 members);
 - WORLWIDE DISSEMINATION and large support to NEW COMMUNITIES
 - ACADEMIA-INDUSTRY MATCHING EVENTS
 - TRAINING & SCHOOLS
- Major progress in the MPGD technologies development in particular large area GEM (single mask), MicroMegas (resistive),
 THGEM; some picked up by experiments (including LHC upgrades);
 - MPGD selected for HEP & NP experiments as a result of these major progresses.
 - > PHASE-DRIVEN (R&D or production) SUPPORT
 - NEW REQUIREMENTS (future experiment driven) and NEW AREA of USE
- Secured future of the MPGD technologies development through the TE MPE workshop upgrade and FP7 AIDA contribution;
 - CERN MICRO PATTERN TECHNOLOGY WORKSHOP scaled up to SQUARE METERS detector size
- Contacts with industry for large volume production, MPGD industrialization and industrial runs;
 - CONSOLIDATION of the industrial PRODUCTION and manufacturing QUALITY for ALL the main MPGD families.
- ✓ Major improvement of the MPGD simulation software framework for small structures allowing first applications;
 - IMPROVEMENTS on METHODS and TECHNIQUES; APPLICATION for MPGD optimization
- Development of common, scalable readout electronics (SRS) (many developers and > 50 user groups); Production (PRISMA company and availability through CERN store); Industrialization (re-design of SRS in ATCA in EISYS);
 - SUPPORT and continuous DEVELOPMENT
 - NEW BASELINE FE ASICS (from experiment development) and STRUCTURES.
 - Development of EASILY accessible MPGD laboratory INSTRUMENTATION.
- ✓ Infrastructure for common RD51 test beam and lab facilities (>20 user groups)
 - Largely ENLARGED infrastructure for the RD51 LAB. REFINEMENT of the TEST BEAM infrastructure.



Summary

- GEM is a mature technology for future particle physics experiments
- Performances of GEM detectors in term of rate capability, position resolution and low mass material ⇒ Ideal candidate for high precision tracking
- Recent effort in the large area GEM detector technology


 Optimization for Forward Trackers
- Vast ongoing R&D program ongoing in the US for EIC, sPHENIX, SoLID GEM based forward tracking system
- University of Virginia, Florida Tech and Temple University leading US effort in large area GEM technology within the eRD6-eRD3 EIC detector R&D program



Back Up



Breakthrough With Large GEMs: Single Mask Technique





Chemistry etching the copper

Cylindrical GEM: KLOE-2 Inner tracker @ Frascati, Italy G. Bencivenni



