Spin information

+ a little about PHENIX DB/Star Scalers

* Many parts of contents borrowed from Ciprian G., Scott W., and Yoshi F.

Chong Kim

SpinFest @ Urbana-Champaign Aug 4th, 2014

Outline

- Access PHENIX database
 - Simple psql commands
- Spin database
 - What is it?
 - What you can get
 - How to access
 - Caveats
- Star Scalers

Access PHENIX database

This part is prepared thanks to Daniel J.

PHENIX DBs

- https://www.phenix.bnl.gov/WWW/offline/wikioff/index.php/Database
- To access,

```
[rcas]$ psql -h "DB_SERVER" "DB_NAME"

ex. $ psql -h phnxdb1.phenix.bnl.gov dag ← access "dag" in "phnxdb1.phenix.bnl.gov"
```

To list,

 \d

To quit,

\q

```
[ckim@rcas2071 al] psql -h phnxdb1.phenix.bnl.gov daq
psql (9.2.4, server 8.4.1)
WARNING: psql version 9.2, server version 8.4.
         Some psql features might not work.
Type "help" for help.
dag=> \d
                    List of relations
 Schema
                                                    Owner
 public | bbcll1thresh
                                         table
                                                    phnxrc
 public | beamxcounters
                                         table
                                                    phnxrc
 public |
         bufferbox
                                         table
                                                    phnxrc
 public | ccftransfer
                                         table
                                                    phnxrc
 public | ccjtransfer
                                         table
                                                    phnxrc
 public |
         cpuusage
                                         table
                                                    phnxrc
 public |
          dcmlist
                                         table
                                                    phnxrc
 public | fvtx fibers latched
                                         table
                                                    phnxrc
 public | fvtx fibers latched version
                                         table
                                                    phnxrc
 public |
          fvtx fphx mask
                                         table
                                                    phnxrc
 public | fvtx fphx mask version
                                         table
                                                    phnxrc
 public |
          fvtx fphx status
                                         table
                                                    phnxrc
          fvtx fphx status version
 public |
                                         table
                                                    phnxrc
 public
          fvtx scalars
                                         table
                                                    phnxrc
```

```
dag=> \d bbcll1thresh
      Table "public.bbcll1thresh"
                           Modifiers
            integer | not null default 0
 channelnb
             integer
                      not null
 t1thresh
            integer
 t2thresh
            integer
Indexes:
    "bbcll1thresh pkey" PRIMARY KEY, btree (runnumber, channelnb)
dag=> \d beamxcounters
      Table "public.beamxcounters"
                          Modifiers
            Type
 runnumber | bigint |
                     not null default 0
 beamx0bbr
            bigint
 beamx1bbr
            bigint
 beamx0abr
            bigint
 beamx1abr
            bigint
 beamx0ber
            bigint
 beamx1ber
            bigint
 beamx0aer
            bigint
beamx1aer | bigint
    "beamxcounters_pkey" PRIMARY KEY, btree (runnumber)
```

Access PHENIX database

PHENIX DBs

daq=> select run.runtype from run where(run.runnumber = 367593);
runtype
----PHYSICS
(1 row)

To query, after DB access

```
"DB_NAME"=> select "TABLE"."VARIABLE" from "TABLE" where ("CONDITION");
ex. daq=> select run.runtype from run where (run.runnumber = 367593);

* This will also spit out something as well:
    "DB_NAME"=> select "VARIABLE" from "TABLE" where ("CONDITION");
but I don't recommend as it's NOT specific. Better safe than sorry
```

The "CONDITION" can be much more complicated in real life...

You can find good documentation in here: http://www.postgresgl.org/docs/8.2/static/sgl-select.html

Access PHENIX database

- You can access it directly through: psql commands, script, and C++ (ROOT)
 - Example of psql command works in RCF/script:

```
psql -t -d daq_phnxdbrcf2_A -U phnxrc -c "QUERY";
ex.
psql -t -d daq_phnxdbrcf2_A -U phnxrc -c "select run.runtype from run where (run.runnumber = 367593)";
```

– Example by using bash script:

```
phnxrc@va019.phenix.bnl.gov:/home/phnxrpc/danielj/utility_scripts/combine_fills_run13.sh
```

– Example by using root:

```
https://www.phenix.bnl.gov/viewvc/viewvc.cgi/phenix/online/analysis/rpc/rpc_ga/process_pdst.C
```

- * Check from 139th lines ↑
- Usually DBs can be accessed from RCF, but some DBs only can be accessed from PHENIX machines (ex. va019)

Spin DB What is it?

- For any kind of spin (or asymmetry) analysis you need: fill pattern, spin pattern, beam polarization, etc.
- Official spin information of Spin PWG
- CDEV, V124 → spin_oncal, spin_daq → (+ QA) → spin DB
 - Two ways to get the raw information from collected data
 - CDEV: CAD transmit to each experiment at the beginning of every fill. This is basically a statement how they intend to fill each beam WRT spin pattern
 - V124: automatically generated when the ring is actually filled. Once we have spin pattern we use out triggers to determine where the first bunch exist in our data
 - spin_oncal for spin related info (Spin pattern, etc), spin_daq for GL1p info (Bbc/Zdc)
- Beware the spin information measured at IP12. <u>NOT PHENIX</u>
- Most importantly, do NOT trust this information blindly

Spin DB What you can get

- Fill number
- Run number
- Crossing shift (XingShift)
- QA info
 - QA level (level of QA for stored data. Current = 2)
 - Bad run (Run QA, 0:good, 1:bad) usually empty
 - Bad bunch (Bad bunch QA, 0:good else:bad)
- Beam polarization info: for each beam (Blue/Yellow),
 - Polarization value and its error (both statistic/systematic)
 - Polarization's <u>transverse component</u> (both horizontal/vertical) value and its <u>error</u>
- Spin pattern
- GL1p scaler counts
 - BBCLL1 w/wo vtx cut
 - ZDCLL1 wide/narrow cut

Spin DB How to access

- Access by psql query: in RCF,
 - psql -h phnxdb1.phenix.bnl.gov spin, then \d spin

Library <u>uspin</u>

- https://www.phenix.bnl.gov/viewvc/viewvc.cgi/phenix/offline/packages/uspin/
- A sample macro written by Y. Fukao (10 years old, but still intact and works well):

```
/phenix/WWW/p/draft/fukao/SpinDB/SpinDBSample.C

to run,

root[0] gSystem->Load("libuspin.so");

root[1] .x SpinDBSample.C(Runnumber Start, Runnumber End)
```

Also a little "messy" example of mine which returns result in root file:

/direct/phenix+scratch/ckim/al/AccessSpinDB.C

Library <u>SpinDBUpdater</u>

- https://www.phenix.bnl.gov/viewvc/viewvc.cgi/phenix/offline/analysis/SpinDBUpdater/
- Mainly developed to update the DB, but it has all getter methods in uspin you need

Spin DB How to access

Result of example (Y. Fukao) macro running

```
-rw-r--r-- 1 ckim rhphenix 1891 Jul 31 18:23 SpinDBSample.C
[ckim@rcas2071 al]$ root -1
root [0] gSystem->Load("libuspin");
root [1] .x SpinDBSample.C(367593, 367593);
Run number = 367593
Fill number = 16698
Bad run QA = 0
Crossing shift = 5
         40341989
                      21488463
                                   3557666
                                                7116078 : 1 1 : 0 : 0.549 +- 0.030 : 0.566 +-
                                                     0: -1
                                                             1:0:0.549 +- 0.030: 0.566 +-
 1:
                                         Ø
 2:
         41701381
                      22079337
                                   3755871
                                               7570437 : 1 -1 : 0 : 0.549 +- 0.030 : 0.566 +-
 3:
         40880111
                      21656569
                                   3640513
                                                                       0.549 +-
                                                                                0.030 :
                                                                                         0.566 +-
 4:
         40958667
                     21639555
                                   3661554
                                                7401812 : -1
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 5 :
         41404723
                     21762224
                                   3760171
                                                             1 : 0 : 0.549 +- 0.030 : 0.566 +-
         43722593
                     22810525
                                   4105666
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
                                                8485120 : -1 -1 : 0 :
         45277562
                      23638793
                                                             -1:0:0.549 +- 0.030: 0.566 +-
 7 :
                                   4337955
                                                8955714 : 1
 8 :
         44144409
                     22976433
                                   4194853
                                                              1:0:0.549 +- 0.030: 0.566 +-
 9:
         44625485
                      23137416
                                   4282946
                                                8961123 : -1
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 10:
         45785009
                      23654576
                                   4472812
                                                9418249 :
                                                             -1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 11 :
         44581068
                      22991527
                                   4308608
                                                                       0.549 +- 0.030 : 0.566 +-
                                                9097050 : -1
                                                             -1:0:
 12:
         43858416
                     22649597
                                   4211830
                                                8869382 : -1
                                                              1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 13:
         42534743
                      21976495
                                   4029598
                                                              1:0:0.549 +- 0.030: 0.566 +-
                                                8475227 : 1
                     22633416
                                                             -1:0:0.549 +- 0.030: 0.566 +-
 14:
         43994919
                                   4247328
                                                9000535 : -1
 15:
         43511392
                      22400326
                                   4181634
                                                                       0.549 +- 0.030 :
                                                              -1:0:
                                                                                         0.566 +-
 16:
         42200224
                      21716492
                                   3991300
                                                8421779 :
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 17 :
         44680216
                      22961508
                                   4358866
                                                                       0.549 +- 0.030 :
 18:
         44460401
                      22920411
                                   4312966
                                                9119123 :
                                                             -1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 19:
         46539153
                      23938121
                                   4635094
                                                9860122 : -1 -1 : 0 : 0.549 +- 0.030 : 0.566 +-
 20 :
         46664660
                      23942468
                                   4666115
                                                9980443 : -1
                                                                       0.549 +- 0.030 : 0.566 +-
 21 :
         46078365
                     23653201
                                   4607205
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 22 :
         46240098
                      23654436
                                   4645659
                                                9968218 : -1
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
                                                             -1 : 0 :
 23:
         47288417
                      24128829
                                   4819068
                                                                       0.549 +- 0.030 :
 24:
         47162918
                      24064834
                                   4795350
                                                              1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 25 :
         46241975
                      23638415
                                   4636805
                                               9953229 : -1
                                                              1 : 0 : 0.549 +- 0.030 : 0.566 +-
 26:
         45916986
                      23505063
                                   4580829
                                                                       0.549 +- 0.030 : 0.566 +-
27 :
         46308237
                      23723011
                                   4640648
                                               9929743 : -1
                                                             -1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 28:
         47288413
                      24187269
                                   4798580
                                              10321244 : -1
                                                              1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 29:
         47664976
                      24383533
                                   4858907
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 30 :
         45216460
                      23175011
                                   4472747
                                               9565580 : -1 -1 : 0 :
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 31 :
         47178699
                      24025716
                                   4813867
                                              10493123 :
                                                             -1 : 0 : 0.549 +- 0.030 : 0.566 +-
 32 :
         47019475
                      23959433
                                   4791379
                                                                       0.549 +- 0.030 : 0.566 +-
 33 :
         47337249
                      24209005
                                   4819853
                                              10419914 : -1
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 34 :
         47629356
                      24333043
                                   4870169
                                              10547518 :
                                                             -1:0:
                                                                       0.549 +- 0.030 :
                                                                                         0.566 +-
 35 :
         49270806
                      25198590
                                   5122471
                                              11079136 : -1 -1 : 0 : 0.549 +- 0.030 : 0.566 +- 0.066
```

Spin DB Caveats – Existing Spin DB QA


Spin DB QA

- First things first: for Run 12/13, thorough QA note exist
 - Run12: http://www.phenix.bnl.gov/WWW/p/forms/info/show_note.php?editkey=an1096
 - Run13: http://www.phenix.bnl.gov/WWW/p/forms/info/show_note.php?editkey=an1125
- The info in Spin DB are updated values after these QA
- QA items:
 - Existence of the information in the DB
 - Polarization values' match between values in the DB and official released values
 - Spin patterns/crossing shifts consistency between all runs within a given fill
 - GL1p scaler values' match to the other scaler for each run

Spin DB Caveats – Crossing shift calibration

Crossing shift calibration


- We need to find where is the first bunches in our data by using our trigger system
- Usual crossing shift is 5 (= first bunch exist in crossing #5). But <u>NOT</u> always.
- Usually last 9 bunches (110 ~ 119) are empty for the beam dump (abort gap)



Be careful when you use uspin library

- uspin library had PHENIX getter method in addition to normal getter method
- It automatically correct crossing shift, but I recommend you correct XingShift by yourself:
 updated crossing = (raw crossing + XingShift)%120

Spin DB Caveats – Flipped spin pattern between IP12 & IP8 (PHENIX)



Spin pattern flips due to Siberian snake

- Spin patterns in DB: +1 for spin up, -1 for spin down, 0 for unpolarized, and 10 for empty
- As explained, our spin pattern measured at 12'o clock
- For longitudinal polarized runs, Spin up becomes positive helicity therefore correction is NOT necessairy
- For transverse polarized runs, Spin flips up to down

Star Scalers

- Simply, it is a Scaler which can accept many input at the same time
 - https://www.phenix.bnl.gov/WWW/offline/wikioff/index.php/How_to_STAR_Scaler
 - For those who study about True/Relative luminosity study you may need info in Star
 Scaler in addition to existing GL1p
- Library StarScaersAuto
 - https://www.phenix.bnl.gov/viewvc/viewvc.cgi/phenix/offline/analysis/StarScalersAuto/
 - Flags for Years so far (ex. Run12) are prepared by developer (A. Manion)