

Overview of the Experiment

BNL – GSI Meeting, Brookhaven National Laboratory, November 21st - 22nd 2011 Lars Schmitt, GSI Darmstadt


- Antiprotons at FAIR
- PANDA Physics and Spectrometer

Highlights: GEM Tracker, DIRC, PWO Calorimeter

Cooperation Topics



Facility for Antiproton and Ion Research



New facility featuring:

Rare isotope beams, heavy ion beams, anti-protons

→ Optimal usage of accelerator facilities



PANDA Overview L. Schmitt, GSI

Layout of the Facility

Primary beams


- U up to 35 AGeV
- Protons up to 30 GeV/c
- 100-1000x more

Secondary beams

- Broad range of rare isotopes, 10000x more
- ₱: 0-15 GeV/c

Storage and cooler rings

- Radioactive beams
- e A (or p A) collider
- Antiprotons



Antiprotons at FAIR




Antiproton production

- Proton Linac 70 MeV
- Accelerate p in SIS18 / 100
- Produce p on Cu target
- Collection in CR, fast cooling
- Accumulation in RESR, slow cooling
- Storage in HESR and usage in PANDA

Modularised Start Version

- RESR is postponed (Mod. 4)
- Accumulation in HESR
- 10x lower luminosity





Antiprotons at FAIR




Antiproton production

- Proton Linac 70 MeV
- Accelerate p in SIS18 / 100
- Produce p on Cu target
- Collection in CR, fast cooling
- Accumulation in RESR, slow cooling
- Storage in HESR and usage in PANDA

Modularised Start Version

- RESR is postponed (Mod. 4)
- Accumulation in HESR
- 10x lower luminosity





Antiprotons at FAIR




Antiproton production

- Proton Linac 70 MeV
- Accelerate p in SIS18 / 100
- Produce p on Cu target
- Collection in CR, fast cooling
- Accumulation in RESR, slow cooling
- Storage in HESR and usage in PANDA

Modularised Start Version

- RESR is postponed (Mod. 4)
- Accumulation in HESR
- 10x lower luminosity







High Energy Storage Ring

HESR Parameters


- Storage ring for internal target
- Initially also used for accumulation
- Injection of p at 3.7 GeV/c
- Slow synchrotron (1.5-15 GeV/c)
- Luminosity up to L~ 2x10³² cm⁻²s⁻¹
- Stochastic & electron cooling
- Energy resolution ~50 keV
- Tune E_{CM} to probe resonance
- Get precise m and Γ







The PANDA Experiment at FAIR



Physics Goals of PANDA

Hadron Spectroscopy

Experimental Goals: mass, width & quantum numbers J^{PC} of resonances

Charm Hadrons: charmonia, D-mesons, charm baryons

→ Understand new XYZ states, D_s(2317) and others

Exotic QCD States: glueballs, hybrids, multi-quarks Spectroscopy with Antiprotons:

Production of states of all quantum numbers Resonance scanning with high resolution



Physics Goals of PANDA

Hadron Spectroscopy

Experimental Goals: mass, width & quantum numbers J^{PC} of resonances

Charm Hadrons: charmonia, D-mesons, charm baryons

→ Understand new XYZ states, D_s(2317) and others

Exotic QCD States: glueballs, hybrids, multi-quarks Spectroscopy with Antiprotons:


Production of states of all quantum numbers Resonance scanning with high resolution

Hadron Structure

Generalized Parton Distributions

→ Formfactors and structure functions, L_a

Timelike Nucleon Formfactors
Drell-Yan Process





Physics Goals of PANDA

Hadron Spectroscopy

Experimental Goals: mass, width & quantum numbers J^{PC} of resonances

Charm Hadrons: charmonia, D-mesons, charm baryons

→ Understand new XYZ states, D_s(2317) and others

Exotic QCD States: glueballs, hybrids, multi-quarks Spectroscopy with Antiprotons:

Production of states of all quantum numbers Resonance scanning with high resolution



Generalized Parton Distributions

→ Formfactors and structure functions, L_a


Timelike Nucleon Formfactors
Drell-Yan Process


Nuclear Physics

Hypernuclei: Production of double Λ-hypernuclei

γ-spectroscopy of hypernuclei, YY interaction


Hadrons in Nuclear Medium















Detector requirements:

- 4π acceptance
- High rate capability:
 2x10⁷ s⁻¹ interactions
- Efficient event selection
- → Continuous acquisition
- Momentum resolution ~1%
- Vertex info for D, K⁰_S, Y
 (cτ = 317 μm for D[±])
- → Good tracking
- Good PID (γ, e, μ, π, K, p)
- → Cherenkov, ToF, dE/dx
- γ-detection 1 MeV 10 GeV
- → Crystal Calorimeter




TARGET SPECTROMETER FORWARD SPECTROMETER




PANDA Overview

L. Schmitt, GSI

TARGET SPECTROMETER FORWARD SPECTROMETER



TARGET SPECTROMETER FORWARD SPECTROMETER




Micro Vertex Detector

Design of the MVD

- 4 barrels and 6 disks
- Continuous readout
- Inner layers: hybrid pixels (100x100 μm²)
 - ToPiX chip, 0.13µm CMOS
 - Thinned sensor wafers
- Outer layers: double sided strips
 - Rectangles & trapezoids
 - 128 channel readout ASIC
- Mixed forward disks (pixel/strips)

Challenges

- Low mass supports
- Cooling in a small volume
- Radiation tolerance



Micro Vertex Detector




Design of the MVD

- 4 barrels and 6 disks
- Continuous readout
- Inner layers: hybrid pixels (100x100 μm²)
 - ToPiX chip, 0.13µm CMOS
 - Thinned sensor wafers
- Outer layers: double sided strips
 - Rectangles & trapezoids
 - 128 channel readout ASIC
- Mixed forward disks (pixel/strips)

Challenges

- Low mass supports
- Cooling in a small volume
- Radiation tolerance



Radiation map of $\overline{P}ANDA$ MVD




Central Tracking Detectors

Central Tracker:

- Design figures:
 - \bullet σ_{ro} ~150 μ m , σ_{z} ~1 μ m
 - δp/p~1% (with MVD)
 - Material budget ~1% X₀
- Straw Tube Tracker Design:
 - 27 µm thin mylar tubes, 1 cm Ø
 - Stability by 1 bar overpressure
 - Planar layers for compactness
 - Skewed layers for z-coordinate

Forward GEM Tracker:

- Large area GEM foils
- Ultra thin coating
- 3 Stations



Central Tracker:

L = 150 cm

 $R_{in} = 15 \text{ cm}$

 $R_{out} = 42 \text{ cm}$

Readout 15 cm in z

GEM Tracker:

z = 120-180 cm

 $R_{in} = 5 \text{ cm}$

 $R_{out} = 42-88 \text{ cm}$

Readout at periphery



The Straw Tube Tracker

Detector Layout

 4204 straws in 20-26 layers, of which 8 layers skewed at ~3°

Tube made of 27 µm thin Al-mylar, Ø=1cm

 R_{in} = 150 mm, R_{out} = 420 mm, I=1500 mm


Self-supporting straw double layers at ~ 1 bar overpressure (Ar/CO₂)

Material Budget

- Max. 26 layers,
- 0.05 % X/X₀ per layer
- Total 1.3% X/X₀

Detector Studies


- Prototype construction & tests
- Aging tests: up to 1.2 C/cm²
- Cosmic tests for dE/dx
- Simulations of field and detector





Forward GEM Tracker

Forward Tracking inside Solenoid

- 3-4 stations with 4 projections each
 - → Radial, concentric, x, y
- Central readout plane for 2 GEM stacks
- Large area GEM foils from CERN (50µm Kapton, 2-5µm copper coating)
- ADC readout for cluster centroids
- → Approx. 35000 channels total
- Challenge to minimize material










GEM Tracker Design



- Modular design, stable circular arrangement
- Large GEM foils glued in the middle
- Carbon fibre reinforced support riddle
- Cable ducts with integrated power and cooling




Light-weight support riddle






PANDA Overview L. Schmitt, GSI

GEM Tracker Design





Light-weight support riddle


- Modular design, stable circular arrangement
- Large GEM foils glued in the middle
- Carbon fibre reinforced support riddle
- Cable ducts with integrated power and cooling






PANDA Overview L. Schmitt, GSI

Prototype GEM TPC



GEM-TPC Concept

- Continuous sampling
- GEMs to reduce ion feedback
- Approx. 10k pads
- Gas Ne/CO₂, material ~ 1% X/X₀
- Challenges: space charge and high data rate



GEM-TPC Collaboration


TU Munich, GSI Darmstadt, HISKP Bonn, SMI Vienna, Heidelberg University


Project started as development for PANDA, but is now continued as independent technology development




Assembly of GEM-TPC












PANDA Overview L. Schmitt, GSI

Results of GEM TPC in FOPI




Forward Tracking

Tracking in Forward Spectrometer

- 3 stations with 2 chambers each
 - FT1&2 : between solenoid and dipole
 - FT3&4 : in the dipole gap
 - FT5&6 : largest chambers behind dipole
- Straw tubes arranged in double layers
 - 27 µm thin mylar tubes, 1 cm Ø
 - Stability by 1 bar overpressure
- 3 projections per chamber (0°, ±5°)

Modular layout of straws









PANDA DIRC Detectors


Detection of Internally Reflected Cherenkov light







BaBar type Barrel DIRC





- Pin hole focusing
- Large water tank
- Readout with PMTs(BaBar 11000, PANDA 7000)




PANDA DIRC Detectors











PANDA Barrel DIRC




- Shorter radiator
- No large tank





6 5 ii -

PANDA DIRC Detectors

Detection of Internally Reflected Cherenkov light









PANDA Barrel DIRC

- Shorter radiator
- No large tank



PANDA Disc DIRC

Disc shaped radiator




L. Schmitt, GSI

DIRC Radiator Production

- Production of large fused silica pieces (bars, plates, disk segments) is challenging
 - DIRCs require mechanical tolerances on flatness, squareness, and parallelism with optical finish and long sharp edges
 - → difficult, potentially expensive, few qualified vendors worldwide
- BABAR-DIRC used bars polished to 5 Å rms, non-squareness < 0.25 mrad, successfully done for BABAR, need to qualify/retrain vendors 10+ years later
- Can afford to relax some of those specs for PANDA DIRCs due to shorter photon paths (surface roughness 10-20 Å rms, non-squareness 0.5-1 mrad, etc)
- Several good candidates for synthetic fused silica material (Heraeus, Corning)
 - Working with potential vendors in Europe and USA obtained prototype bars, plates, disk segments from several companies, verifying surfaces and angles










DIRC Photon Detection


- PANDA DIRCs pose challenges to fast compact multi-pixel photon detectors
- Single photon sensitivity, low dark count rate
- Reasonably high photo detection efficiency
- Fast timing: $\sigma(TTS) \approx 100 \text{ ps}$
- Few mm position resolution
- Operation in up to 1 1.5 T magnetic field
- Tolerate high rates up to 2 MHz/cm² (Barrel: 0.2 MHz/cm²)
- Long lifetime: 4-10 C/cm² per year at 10⁶ gain (Barrel: 0.5 C/cm²/yr)
- No currently available sensor matches all criteria promising candidates: MCP-PMTs, MAPMTs, SiPM
- Starting aging test of two very new enhanced lifetime MCP-PMTs side-by-side: Hamamatsu SL-10 and Burle 85112 both may be (almost) acceptable for barrel DIRC
- Digital SiPM (Philips) promising sensor for Disk: excellent timing and lifetime, integrated readout electronics, masking of hot pixels
 But: needs cooling, needs redesign for single photons, new technology, prototypes only




PANDA Overview

DIRC Prototype Work











Radiator Testbench at GSI



- 1) Laser (405, 532, 635 nm)
- 2) Polarizer
- 3) Beam splitter
- 4) Diaphragm
- 5) Brewster mirror
- 6) Bar on x, y stage
- 7) Value Diode
- 8) Reference Diode





PANDA Overview

Scintillator Tile Hodoscope

Detector for ToF and event timing

- Scintillator tiles 3x3x0.5 cm³
 - → BC404, BC408 or BC420
 - → Space points with precision timing
 - → Lowest possible material budget
- Photon readout with 2 SiPMs (3x3 mm²)
 - High PDE, time resolution, rate capability
 - Work in B-fields, small, robust, low bias
 - High intrinsic noise
 - Temperature dependence
- Goal for time resolution: 100 ps
- ASIC for SiPM readout





Electromagnetic Calorimeters

PANDA PWO Crystals

- PWO is dense and fast
- Low γ threshold is a challenge
- Increase light yield:
 - improved PWO II (2xCMS)
 - operation at -25°C (4xCMS)
- Challenges:
 - temperature stable to 0.1°C
 - control radiation damage
 - low noise electronics
- Delivery of crystals started





Electromagnetic Calorimeters

PANDA PWO Crystals

- PWO is dense and fast
- Low γ threshold is a challenge
- Increase light yield:
 - improved PWO II (2xCMS)
 - operation at -25°C (4xCMS)
- Challenges:
 - temperature stable to 0.1°C
 - control radiation damage
 - low noise electronics
- Delivery of crystals started




Barrel Calorimeter

- 11000 PWO Crystals
- LAAPD readout, 2x1cm²
- $\sigma(E)/E \sim 1.5\%/\sqrt{E} + const.$

Forward Endcap

- 4000 PWO crystals
- High occupancy in center
- LA APD or VPT




Backward Endcap for hermeticity, 560 PWO crystals **Forward EMC** shashlyk behind dipole



Readout with Large Area APD

- Development of LA APDs with Hamamatsu
 - Large area at acceptable capacitance:
 4x area of previously available APDs
 - Excellent performance at RT and -25°C
 - Radiation tolerance up to 10¹³ protons/cm² in particular at -25°C





1x1 cm² 0.5x0.5 cm²

- Screening of all APDs needed to reach best resolution and stability
- A mass screening facility is under construction at GSI


Courtesy A. Wilms




Readout with Large Area APD

- Development of LA APDs with Hamamatsu
 - Large area at acceptable capacitance:4x area of previously available APDs
 - Excellent performance at RT and -25°C
 - Radiation tolerance up to 10¹³ protons/cm² in particular at -25°C
 - To accommodate 2 APDs per crystal: rectangular APD with 7x14 mm²
- Readout via discrete amplifier or APFEL ASIC






10x10 mm² and 7x14 mm²



18mm




- 2 channels/ 2 ranges
- overall range 1 10.000
- noise level (cooled)< 2 MeV

Courtesy A. Wilms




PWO Prototype Performance

Beam Tests at MAMI



deposited energy / MeV




- Single 1x1 cm² APD with discrete amplifier
- Digitization: shaping /peak-sensing ADC
- Even improved with 100 MHz sampling ADC
- Ongoing tests with APFEL ASIC


Courtesy R. Novotny



Radiation Damage in PWO

- Radiation induced absorption reduces light yield
- At RT recovery by annealing
- At -25°C annealing is slower
- PANDA crystals: control radiation induced absorption loss dk






Courtesy R. Novotny




Stimulated Recovery of PWO

Discovery of stimulated recovery

- Measurement at T=-25°C
- Irradiation with 30 Gy (60Co)
- Damage and recovery characterized by light yield (60Co)
- Illumination with LEDs of different color
- Crystals of different rad. hardness (dk)





- Online recovery with IR light
- Fast recovery with blue light

Courtesy R. Novotny




Muon Detector System


Muon system rationale:

- Low momentum particles
- High background of pions
- Multi-layer range system

Muon system layout:

- Barrel: 12+2 layers in yoke
- Endcap: 5+2 layers
- Muon Filter: 4 layers
- Forward Range System:
 - 16+2 layers
 - Iron absorbers
- Detectors: Drift tubes with wire & cathode strip readout








PANDA Data Acquisition

Self triggered readout

- Components:
 - Time distribution system
 - Intelligent frontends
 - Powerful compute nodes
 - High speed network
- Data Flow:
 - Data reduction
 - Local feature extraction
 - Data burst building
 - Event selection
 - Data logging after online reconstruction
- Programmable Physics Machine





Topics for Cooperation



Physics Topics

- Structure functions
 - Drell Yan process
 - Transversity
- Hadrons in Medium
 - Mass and width modifications
 - Suppression of states
- Hypernuclei

Detector Topics

- Expertise at GSI:
 - Large area APDs
 - Development of DIRCs
 - Light-weight GEM-TPC development
- Expertise at BNL:
 - Polarized beams
 - GEM detectors
 - → Coop on large area GEMs
 - Silicon vertex detectors
 - → Coop on Readout ASICs
 - High rate DAQ systems



Summary



BNL future developments

- High luminosity running at RHIC
- EIC: Physics of structure functions
- → New high rate setups

PANDA & FAIR start in hadron physics from 2018

- Versatile physics machine with full detection capabilities
- PANDA will shed light on many of today's QCD puzzles
- Beyond PANDA further plans for spin physics at FAIR exist

Cooperation of GSI/FAIR and BNL

- Mutual benefits for future
- Exchange of expertise
- Physics and detector topics




Backup Slides







Single Mask GEM









Chemical Polyimide etching




Copper electro etching






Stripping







Second Polyimide etching



Reality


Rui Oliveira, CERN




Single Mask GEM



Single mask GEM from CERN



Double mask GEM from external company




Critical items:

- Time critical etching
- Highly homogeneous etching solution



Largest Size GEM Foils: CMS

CMS Muon Upgrade: 99 cm x 45.5cm x 22 cm (6 pieces)





PANDA Overview L. Schmitt, GSI