

# Check List for the daily measurements

- Establish pre-measurement routine for the day.
  - Check RACK power status
  - Check cooling (30GPH/ROC, 10GPH/ladder), GUI is under bug fix by Steve and Rob.
  - Let shift leader know the activities. (make e-log entry at the end)
  - **Make sure turn off the ROC/FPHX after the measurement**

Experiment Rack Status		
PRR 3.2	PRR 4.1	PRR 4.2
1E1	1E2	1E3
1W1	1W2	1W3
2E1	2E2	2E3
2W1	2W2	2W3
3A1	3B1	3C1
3A2	3B2	3C2
3A3	3B3	3C3
3A4	3B4	3C4
3A5	3B5	3C5
3A6	3B6	3C6
	3B7	3C7
	3B8	3C8
	3B9	3C9

